

June 30, 1975

COPY 2.

APPENDIX I

of

FINAL REPORT

AMPS DATA MANAGEMENT REQUIREMENTS STUDY

Prepared for

GEORGE C. MARSHALL SPACE FLIGHT CENTER
Marshall Space Flight Center, Alabama


Contract No. NAS8-31208

(NASA-CR-143996) AMPS DATA MANAGEMENT
REQUIREMENTS STUDY, APPENDIX 1 Final Report
(TRW Systems Group) 235 p CSCL 09B

N76-11737

Unclas
G3/60 03983

Space Sciences Department
TRW SYSTEMS, One Space Park
Redondo Beach, California 90278



TRW Report No. 26487-6008-RU-00

June 30, 1975

APPENDIX I

of

FINAL REPORT

AMPS DATA MANAGEMENT REQUIREMENTS STUDY

Prepared for

GEORGE C. MARSHALL SPACE FLIGHT CENTER
Marshall Space Flight Center, Alabama

Contract No. NAS8-31208

Space Sciences Department
TRW SYSTEMS, One Space Park
Redondo Beach, California 90278

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	1
2.0 GENERAL ASSUMPTIONS	1
3.0 FUNCTIONAL DESCRIPTION	3
4.0 DISPLAY FORMATS	13
5.0 OPERATING SYSTEM INTERFACES	13
6.0 FLOWCHARTS AND DISPLAY FORMATS	17
6.1 WAVE TRANSMISSION EXPERIMENT	18
6.1.1 Performance of the Wave Transmission Experiment . .	19
6.1.2 Default Value Displays	21
6.1.3 Definition of Variables	21
6.1.4 Flowcharts and Display Formats	27
6.2 PASSIVE OBSERVATIONS OF AMBIENT PLASMA EXPERIMENT	79
6.2.1 Definition of Variables	79
6.2.2 Typical Values	83
6.2.3 Flowcharts and Display Formats	85
6.3 IONOSPHERIC MEASUREMENTS WITH THE SUBSATELLITE EXPERIMENT .	155
6.3.1 Definition of Variables	155
6.3.2 Typical Values	155
6.3.3 Flowcharts and Display Formats	157
6.4 ELECTRON ACCELERATOR BEAM MEASUREMENTS EXPERIMENT	163
6.4.1 Definition of Variables	163
6.4.2 Typical Values	166
6.4.3 Flowcharts and Display Formats	167
6.5 LIDAR TRACE OF ACOUSTICAL GRAVITY WAVES IN THE SODIUM LAYER	183
6.5.1 Definition of Variables	183
6.5.2 Typical Values	185
6.5.3 Flowcharts and Display Formats	187
6.6 ADDITIONAL FLOWCHARTS: CONVERSION OF UNITS AND CALIBRATION DATA	229

1.0 INTRODUCTION

All the flow charts and display formats for the simulation of the following five experiments are given in this appendix:

1. Electromagnetic Wave Transmission Experiment
2. Passive Observations of Ambient Plasma
3. Ionospheric Measurements with Subsatellite
4. Electron Accelerator Beam Measurements
5. Lidar Trace of Acoustical Gravity Waves in the Sodium Layer

A detailed explanation of the simulation procedure, definition of variables, and an explanation of how the experimenter makes display choices is also presented. A functional description is included on each flow chart and the assumptions and definitions of terms and scope of the flow charts and displays are presented in the following sections.

Part 3.0 of the AMPS DMRS Final Report contains the theory and summary description of each experiment. All the equations required for the simulation of each experiment along with the required angular transformation for boom control simulation and the equations for the simulation of associated instrument displays are also given. The capability to control and display the associated instrument outputs is described and the special purpose equipment needed to perform these functions is listed.

2.0 GENERAL ASSUMPTIONS


The following general assumptions have been made in approaching the construction of these flowcharts and the associated display layouts.

2.1 HARDWARE SYSTEM

The system on which the flowcharts will be implemented is as diagrammed in Figure 2.1.1. The flowcharts are functional and do not necessarily include or exclude the use of the XDS 930 computer.

2.2 FLOWCHARTING STANDARDS

Flowcharting standards are as specified in MSFC computer program documentation standards, Part 5.3 of the MSFC Programmer Procedures Manual, dated



NOTES:

- (1) Number and type of AMPS dedicated equipment shown may change as a result of experiment selection and approval.
- (2) More than one DIU may be required.

FIGURE 2.1.1

November 1972. A top-down structured programming approach has been maintained in addition to the above standards.

2.3 EXPERIMENTER FLEXIBILITY

The experimenter shall be able to start, stop, enter, change and delete instrument or boom settings in any order without restriction, except where equipment damage would result and safeguards are practical.

2.4 EXPERIMENTER TRAINING

Experimenter training needed to run a CVT experiment should be minimized by making CVT simulation operation self-explanatory to a maximum practicable extent.

2.5 FLEXIBILITY TO ACCOMMODATE CHANGES

The flowcharts and displays need provisions to accommodate new display options and new data processing routines, insofar as practicable.

2.6 DISPLAY STANDARDS

Display standards shall be as specified in "CVT Spacelab Simulator and C&D Subsystem Performance and Design Requirements Specification", 40M35719, MSFC, dated May 28, 1974.

3.0 FUNCTIONAL DESCRIPTION

Functional descriptions are included on each flowchart. To prevent needless repetition, the following description describes elements that are common to all or at least several flowcharts and displays.

3.1 HIERARCHICAL ORGANIZATION OF SOFTWARE

The flowcharts and displays are organized in a hierarchy with one root at the top and the branches extending downward. The points where branches are joined together are called nodes. These are places where the experimenter can choose the branch (the part of the experiment) that he wishes to be doing. Additional branches can be grafted on, or pruned from, each node should this become necessary or desirable.

The root of the tree for all AMPS experiments is "Plasma Physics". At this root (node) the experimenter can choose which experiment he wishes to perform. The root of the current set of flowcharts is an individual experiment, which assumes that the experimenter has already decided to choose this experiment at the Plasma Physics node. The second level is the setup of the individual booms, platforms and instruments, considered as individual building blocks.

Where convenient to the experimenter, this second level may also contain special-purpose combinations of instruments that interact in a special way to serve the experiment.

The third level contains the processing needed to process the logic and data of the instruments or special-purpose combinations.

Logically, there can be defined as many nodes and branches and their levels as the experiment requires.

3.2 DISPLAY HIERARCHY

All major experiment choices are at the discretion of the experimenter and therefore involve a display. This display presents to him the choices that are open at that particular node including his choices of moving from one node to the next. If the experimenter chooses to move from one node to the next, the current display will disappear from his MFDS CRT, and the display appropriate to the next node chosen will be displayed instead. Thus the displays form a display tree that parallels the major nodes in the software.

Each experiment is introduced by a set of flowcharts numbered from 10 to 14 that show the breakdown of the experiment into its basic operations. A display tree is provided that can serve as a roadmap to the experimenter's display interfaces with the experiment. (See Figures 3.2-1, 3.2-2, 3.2-3, 3.2-4, 3.2-5.)

3.3 EXPERIMENTER DISPLAY CHOICES

The following discussion outlines a specific method by which the experimenter will exercise his choices. This method is fundamental to the operation of the experiments to be flowcharted, HOWEVER, THE SPECIFIC

SYMBOLS USED IN WHAT FOLLOWS DO NOT CONSTITUTE A COMPUTER LANGUAGE CHOICE BY TRW. These symbols are used merely for convenience in flowcharting and exposition only and should be interpreted as such.

The following is the meaning of the symbols used on the flowcharts and display formats. The general form of each experimenter entry is: XX:Value. Each part of this entry is described below:

<u>XX</u>	<u>:</u>	<u>VALUE</u>
The "Entry Number", an integer from zero to 99, listed on the left hand margin of the display.	A symbol used as separation between Entry No. and Entry Value.	The "Entry Value", the logical (YES, NO, etc.) or numerical value of the entry made by the experimenter.




FIGURE 3.2-1 DISPLAY TREE




Figure 3.2-2





Figure 3.2-3



DISPLAY TREE

ELECTRON ACCELERATOR
BEAM MEASUREMENTS
EXPERIMENT

Figure 3.2-4




Figure 3.2-5

3.3.1 Example

A specific example will be used to illustrate the operation of the system. In the Wave Transmission Experiment, Display No. 20, the experimenter has 15 choices. Let us assume he wishes to turn the Wave Transmission (W.T.) Instruments ON. He will key in the following symbols on the keyboard:

1:ON

The word ON will appear in the blank provided on line 1: of the display. This entry on the keyboard will turn on and warm up the electronics and controls of all instruments necessary for performance of the Wave Transmission Experiment. After all instruments are warmed up, READY will appear in the box immediately below entry line 1:. If the experimenter wishes to turn the instruments off he will enter:

1:OFF

which will turn the instruments off and cause READY to disappear.

If the experimenter wishes to set up Boom B into position, he will enter:

5:I.

This will cause Display 20 to be replaced by Display 600, from where the experimenter can proceed to specify the particular Boom B position he wants.

3.3.2 Meaning of Entry Values used by Experimenter

There are five entry values that are widely used by the experimenter:

- UP -- This entry value will return the experiment to the next higher node on the tree, and show the display appropriate to that node.
- I -- This entry value will take the experiment down to the next lower node on the tree, along the branch indicated by the specific entry number. Where a specific numerical value choice or logical choice is available on a display, the choice of I instead will cause the default values for that choice to be displayed.
- D -- This entry value will delete all previous experimenter entries for the nodes below the node in which the experimenter currently finds himself. If D is entered for the entire Wave Transmission Experiment (0:D on Display 20) this destroys all previous experimenter entries.

- SPARE -- This is a location on the display where the programmer can insert a new option. This is simplest to accomplish if the new option is based on subroutines or instrument models already available in the existing library. If not, the subroutines supporting the new option must be designed, coded and integrated into the software system.
- I/NO -- These entry values have a fairly complex meaning. If :I is chosen, from this combination of values computer program will show the display appropriate to that choice, and assume that the experimenter values or default values appropriate to that branch are to be chosen in computing subsequent portions of the experiment. :NO chosen from the I/NO combination reminds the experimenter (later in the performance of the experiment) that he did not wish to use this branch or its default. An error message will appear if the experimenter fails to enter a useable alternative choice for the prohibited :NO branch.

If the meaning of the choices available to the experimenter is not obvious to him he can refresh his memory as to their meaning by entering 0:I on his display. This will cause to appear on his CRT display either an instructional display or a page number reference to his instruction manual, containing definition of instrument settings or other items he might need. TRW is not necessarily suggesting that complete instructional text be a part of the CVT computerized system.

The need for this is not clear. The practicality of this will depend on the size, cost and convenience of mass storage use.

3.3.3 Values Displayed to the Experimenter by the Computer

All constants and logical program entries are under the control of the experimenter. However, some quantities are computed by the computer based on these entries and are thus only indirectly under experimenter control. Quantities computed by the computer that are in this sense indirectly under experimenter control are enclosed in rectangular boxes on the display. An example is actual Boom A position length and angles (Display No. 700).

3.3.4 Values Jointly Under the Control of the Experimenter and Computer

It is clear that setting up an experiment may involve making numerous adjustments to several instruments. The flowcharts assume the following protocol to assist the experimenter in keeping track of where he is in setting up his experiments (See Flowchart No. 21).

1. If he enters a D entry value the experimenter's entries at lower levels will be destroyed and their display will show a "?" (question mark). If the experimenter enters 0:D all experimenter entries on the display he is looking at and the subordinate modes will be so destroyed. Default values, however, will not be destroyed by this procedure.
2. If the experimenter fails to enter any choice where a question is displayed, the computer will assume default values for this choice.
3. The entire set of experimenter entries can be destroyed by entering 0:D on Display 20. The experiment can then proceed to the maximum extent based on default values.
4. Whenever the experimenter makes a choice of an entry value, this value is displayed to him on the display where it is made, and remains there until replaced by a question mark. Thus the experimenter can determine by looking at his display, what part of the instrument (non-default) settings he has made.
5. The experimenter may choose to delete a specific entry he made. He does this by entering a "?" in the appropriate location. This entry specifically changes only the value previously entered.

4.0 DISPLAY FORMATS

As in common industrial practice, display formats are here specified in terms of how the display would actually look to the user. The display area shown on each of the suggested displays has been printed on millimeter paper for ease in interpreting the display in terms of X, Y cathode ray tube coordinates. The area used is approximately equal to the undistorted part of the MFDS cathode ray tubes.

5.0 OPERATING SYSTEM INTERFACES

This section describes the capabilities, at a functional level, that the experiments flowcharted will require of the computer operating system. No distinction is made, in what follows between the SUMC and the XDS 930. Either the SUMC above, or the SUMC plus the XDS 930 can be used. If both computers are used, an important computer-to-computer communication function is added to the functions performed by the system. However, in what follows continual reference will not be made to the alternatives raised by these two system configurations.

5.1 EXPERIMENT SIMULATION SUPPORT

Each of the five experiments will be run on a separate (non-concurrent) basis.

5.2 PERIPHERAL USAGE, I/O SUPPORT

It is believed that the SUMC computer or the SUMC/XDS 930 combination can contain in core all the programs specified herein for any one experiment, including the required data and working storage areas and the required operating system(s). Peripheral support is required for loading, assembly, compilation, diagnostic and other maintenance functions but probably not required during simulation of the experiments themselves—with two potential exceptions:

5.2.1

If the (now stubbed) magnetic tape recording of experiment data is implemented—this obviously requires the tape recorder itself as a peripheral.

5.2.2

If there is added a printout or other log of the experimenter's activities for post-simulation analysis of how quickly or how well the experiment was performed.

Obviously, if the scope of the experiment simulation is expanded, or extremely inefficient operations are called for, additional peripheral support may be required.

5.3 MEMORY MANGEMENT SUPPORT

Each experiment consists of individual (building block) tasks. The experimenter has the following options that memory management must support.

5.3.1

During simulation runs, the experimenter may activate various preplanned instruments and displays in sequences and at times of his own choosing.

5.3.2

Between simulation runs, the experimenter may decide to add an additional instrument to the list participating in the previous simulation run, and this may lead to a requirement for additional physical models to support this requirement.

5.3.3

Between simulation runs, the experimenter may decide to change scales on his display, leading (perhaps) to increased size in data regions supporting this display.

5.3.4

Data may be either specific to a single functional area or may be accessed/changed by more than one functional area.

5.3.5

In spite of 5.3.1, 5.3.2, 5.3.3 and 5.3.4 above, the amount of data used and produced by each task within an experiment should be quite accurately predictable.

5.3.6

The plasma physics experiments do not require extreme accuracy. It is believed that all data can adequately be represented by single-precision numbers. For experimental data, floating point representation may be preferable, because of the possibility that large changes in the magnitude of the numbers will be required as the experiment is refined.

5.4 EXPERIMENTER COMMUNICATIONS

All experimenter communications entering the computer via these flowcharts are initiated via the MFDS console keyboard. Some equipment settings (e.g., in the Wave Transmission Experiment) are also initiated from this keyboard. Almost all displays are via the MFDS experimenter CRT. Rapid response of the computer system (e.g., within 4 seconds), to a keyboard command is psychologically desirable but not required for the success of the experiments flowcharted.

5.5 TIMING AND SEQUENCING SUPPORT

This is the area of greatest potential complexity in interfacing with the operating system, because of the multiplicity of demands that may arise. The application programs will need the following types of support:

5.5.1

Tasks that need to be recomputed on a periodic basis (e.g., the current values of astronomy/orbit mechanics quantities need to be recomputed every 2 seconds).

5.5.2

Tasks that need to be recomputed on a periodic basis until a specific end-condition is reached (e.g., boom positioning, platform positioning), and stop thereafter.

5.5.3

Tasks that compute future availability of an experiment resource (e.g., simulate warmup or settling time of a piece of equipment) on a one-time basis.

5.5.4

Tasks that need to be recomputed on a pre-specified basis (e.g., using a display specification to determine when to recompute the data points to be displayed on a two-axis (XY) graphical CRT display, with one of the axes being a time axis).

5.5.5

Tasks that need to be computed only once, as in setting a gain constant in an instrument computation.

5.5.6

Tasks that have been requested, but where no specific need-to-see time is specified (e.g., display of a simulated instrument calibration curve).

5.5.7

Tasks that simulate high-data rate acquisition from a sensor source, but where the processing of this data for display must proceed at a slower rate. This will probably involve buffer allocation and use.

5.5.8

Tasks that have been interrupted and need completion.

5.5.9

Tasks that have not been executed within the timing cycle allocated because of their low priority, but which need to be executed at a later time (possibly involving priority level manipulations).

5.5.10

All tasks need to have the support of a time-out routine. Since the experimenter has the power to alter the constants and the instruments that participate in an experiment, unforeseen situations may arise which can bring the system to a halt. Provision of time-outs will permit the system to continue to simulate the experiment even though some deficiency may temporarily exist.

6.0 FLOWCHARTS AND DISPLAY FORMATS

The flowchart and display format data is presented in three sections. The first two sections define the variables and specify the range of values for specific sets of variables. The flowcharts and display formats are presented in the third section. Each flowchart includes a functional description and is associated with a specific display format simulating the display of the MFDS CRT.

The procedure, sequencing and parametric definition of default values has been carried out in great detail for the Wave Transmission Experiment in order to present an illustrative sample of how the flowcharts can be used. There are, of course, a large number of other options available in the sequencing of the Wave Transmission Experiment, and the four subsequent experiments. Similarly, the selection of typical default values was included

in the Wave Transmission Experiment only in order to strengthen the concept of the experiment flowcharted—particularly the orientation of the orbiter and spacecraft while the measurements are being taken. In general, we believe that the selection of the default values should be left to the experimenter.

6.1 WAVE TRANSMISSION EXPERIMENT

(The experiment procedure for this experiment is given in Section 3.1.2 of the Final Report.)

The key to the understanding of the Wave Transmission Experiment flowchart and displays in Display No. 20. The effect of making entries under Entry Numbers 0: and 1: have already been discussed in Sections 3.3.1 and 3.3.2.

A fixed and unvarying equatorial orbit is assumed for this experiment as orbital variations do not impact the essential concepts of this simulation (Entry No's. 3: and 4:), Astronomy/Orbit Mechanics computations are stubbed for this experiment.

Entries No's. 5: through 12: permit the experimenter to set up his individual experimental instruments. He can do this in any order he pleases, (although he would be wise to set up Boom A before setting up the platform).

Finally, Entry No's. 13: and 14: permit him to investigate the electric and magnetic plasma fields independently and sequentially.

Both a manual and an automatic method of stepping through the range of frequencies of interest is provided as explained below. The choice between these two methods is on Displays 1510 Entry Value 12: for the electric, and on 1616 Entry Value 12: for the magnetic field measurements. If the experimenter does nothing, the automatic sequence will be chosen (see Displays 1511 and 1611).

The Wave Transmission Experiment illustrates graphically the tradeoffs involved in maintaining the instrument-by-instrument building block concept, as against inventing a special purpose experiment concept where the setting of two or more sets of instruments are effected using a single computer-driven display.

For example, Display 1610 gives the opportunity to set both the transmitter center frequency and the receiver frequency band for the magnetic field transmission experiment. By the building block concept, these same settings can be accomplished for the transmitter via Display 1410 and for the receiver in Display 1310. Care must be taken in the software implementation to assure that the convenience to the operator given by 1610 (not having to switch between 1310 and 1410 for every manually controlled experimental frequency setting) is not overbalanced by the time spent implementing and checking out the additional software involved, which is primarily display software.

6.1.1 Performance of the Wave Transmission Experiment

Below is an example of a typical sequence in performing the Wave Transmission Experiment. This typical sequence is included for illustrative purposes only and is not repeated for each experiment.

The job of setting up the instruments and running the experiment can be performed by the experimenter in any sequence that he pleases. It is expected that the experimenter will normally avail himself of the convenience of the automatic frequency sequencing provided. This sequencing automatically adjusts the frequency of both the transmitter and receiver to step through a sequence of frequencies covering the frequency neighborhood that is close to the plasma frequency being investigated here. The experimenter will then go through the following steps (assuming that he does not wish to deviate from the default values provided). Starting with Display No. 20

1. Experimenter enters 0:D on Display 20. This will remove all previous entries, and secure the use of default values for boom, platform and instrument settings. 1:ON turns all instruments ON.
2. Experimenter enters 13:I, this will give him Display 1560 which applies to measuring the mean square electric field \bar{E}^2 .
3. The experimenter notes whether the instruments are ready.
4. The experimenter notes the noise level on his special-purpose receiver display.

5. The experimenter turns the transmitter on (5:GO) on 1560.
6. The experimenter adjusts the transmitter attenuator, (4:) on 1560, until the received signal level is 100 times the previously observed noise level (Step 4).
7. If Display 1560 shows a satisfactory \bar{E}^2 level, the experimenter may wish to record this data and associated instrument settings (6:GO). This will record instrument settings (once) and the \bar{E}^2 data and time for as long as the recorder is on (once per second, for example).
8. When the experimenter believes he has recorded a sufficient amount of \bar{E}^2 data he will stop the recorder (6:STOP).
9. The experimenter will now go to the next frequency by entering (2:YES).
10. The experimenter will now stop the transmission by the transmitter (5:STOP). He is now ready to repeat Steps 4 through 10 above for the next frequency on the automatic frequency list.
11. The experimenter repeats Steps 4 through 10 until he has enough data.

The same sequence as above applies to the measurement of the mean square magnetic field \bar{B}^2 . The exception is that in Step 2 the experimenter will enter 14:I, which will give him Display 1660, which applies to measuring the mean square magnetic field \bar{B}^2 .

If the experimenter wishes to deviate from the automatic frequency sequence, he can negate it by entering 12:NO on Display 1510 for the \bar{E}^2 measurement or entering 12:NO on Display 1610 for the \bar{B}^2 measurement. He is then in the manual mode and can set his own transmitter and receiver frequencies. (Display 1510 or 1610, 4:, 5:, 6:, for example.)

12. At the end of the experiment, the experimenter can preserve his last choices of values by backing up to 20 Wave Transmission Experiment Display by (repeatedly) commanding 0:UP. If he wishes to destroy his entries he can enter 0:D from Display 20.

6.1.2 Default Value Displays

The Wave Transmission Experiment is unique among the experiments flow-charted in that two sets of displays are presented—one which permits the experimenter step-by-step control, and one which permits rapid experiment performance via a (partially) automated sequence.

Which path is followed by the experimenter is up to him. By the simple method of not providing his own on-the-spot instrument settings, boom and platform angles, etc., the experimenter in effect forces the computer program to use a set of pre-assigned parameters called default values. There are so many parameters in the plasma physics experiment, that it would be hazardous for the experimenter to rely on his memory for the values of each of these parameters. Yet the experimenter must know these default values in order to control his experiment intelligently. The default values fit into the display background of the experimenter-selected values with regard to number, type, range, and precision. These displays consume negligible additional computer capacity or speed.

It is believed that the AMPS experimenters should seriously consider having default values for each and every parameter where this is plausible. However, in the Wave Transmission Experiment we have presented a set of default value displays in order to illustrate the concept.

6.1.3 Definition of Variables

The following definitions define variables not defined in Section 3.3 of the general Flowcharts and Display Formats discussion.

READY FLAG

A flag indicating whether or not the equipment(s) participating in a particular operation are warmed up or in place. Calculating a ready flag when more than one equipment is involved means calculating when the last equipment necessary to the operation is ready.

E^2

Mean square value of electric field vector, (Volts/M)² Range 0 to 10⁷, least count 0.1% of full scale displayed value.

\bar{B}^2

Mean square value of magnetic field vector, (Tesla)² Range 0 to 10^{-17} , least count 0.1% of full scale displayed value.

PROBE AXIS

The axis of the cylindrical electron probe, mounted so that the probe axis points in the +Y orbiter direction when $X = \psi = \Omega = \theta_A = \phi_A = 0$ degrees.

ELECTRON TEMPERATURE

A measure of the average energy of the electrons in degrees Kelvin. Range 10^2 to 10^7 . Least count 0.1% of value.

ELECTRON VOLTS

A measure of the energy of a specific electron or group of electrons, in electron Volts. Range 0 to 1000 least count 0.1% of value at full scale.

ELECTRON DENSITY

The number of free electrons in a cubic meter of plasma.

ANGLE BETWEEN PROBE AXIS AND ORBITER VELOCITY

Measured in the Wave Transmission experiment between the -X orbiter axis and the probe axis.

 \bar{B}_T

The earth's total magnetic field vector at the orbiter, in gamma. Range 0 to 10^5 , least count one gamma.

BX, BY, BZ

Components of \bar{B}_T through the magnetometer X, Y, Z coils. Range and least count same as \bar{B}_T . Magnetometer is oriented so that X, Y, Z coil axes are parallel to shuttle X, Y, Z axes when $\Omega = X = \psi = \theta_A = \phi_A = 0$ degrees.

CYCLE

A computer cycle, the time of a major computer update cycle (approximately one or two seconds).

RECEIVER GAIN

The amount of gain in the receiver (pre) amplifier relative to the input signal power in db. Range 0 to 80 db. Least count 1 db. Gain is flat between upper and lower frequency limits.

ROLL OFF

The characteristic way in which response decreases beyond the set frequency limit.

SQU

Square - No signal beyond the frequency limit.

EXP

Exponential decrease in signal level beyond the frequency limit.

LIN

Linear decrease in signal level beyond the frequency limit.

SPECIAL

Special form of decrease in signal level beyond the frequency limit.

 S^2

Signal level ratio S^2 . The proportion by which P_{max} is reduced for the Wave Transmission experiment. Range 0 to 1.000. Least count 0.1% of its value.

TRANSMITTER ATTENUATOR

The attenuation inserted between the transmitter and the transmitting antenna, in db. Attenuation in power ranges from 0 to -80 db. Least count 1 db.

(TRANSMITTING) ANTENNA LENGTH d

The tip-to-tip length of the transmitting antenna. Range 0.0 to 33.0 meters. Least count 0.1 meters.

AUTOMATIC FREQUENCY BANDWIDTH

An equal tolerance about the center transmitter frequency. Applied to the upper and lower receiver frequencies, respectively. Range 0 to 9.99 MHz. Least count 0.01 MHz.

AUTOMATIC FREQUENCY
SEQUENCE

A sequence of frequencies preplanned for the Wave Transmission experiment.

NEXT VALUE OF FREQUENCY

Next value in the automatic sequence.

PREVIOUS VALUE OF
FREQUENCY

Previous value in the automatic sequence. Used to redo a measurement if necessary.

RECORD INSTRUMENT SETTINGS

Record all values set by the experimenter for the instruments that are ON.

r

Effective distance between transmitter and receiver. Range 2 to 100 meters. Least count 0.1 meters.

m

The mass of the electron (Kilograms).

P_{max}

The maximum power of the transmitter that can be used for this experiment (1000 Watts).

e

The charge of the electron (coulombs).

k

The wave number of the transmitted wave (seconds/meter).

c

The velocity of light (meters/second).

w

The frequency of the transmitted signal in radians/second. $w = 2\pi f$.

XYZ

Cartesian coordinate system (right handed) fixed in Orbiter.

X-axis = longitudinal axis of vehicle positive rearward

Y-axis = positive out right "wing"

Z-axis = positive upward

 L_B, θ_B, ϕ_B

Boom "B" tip spherical coordinate system where

L_B = Boom "B" length

θ_B = Boom "B" elevation-measured from Orbiter + Z-axis

ϕ_B = Boom "B" azimuth-measured from Orbiter + X-axis positive about Z.

 L_A, θ_A, ϕ_A

Boom "A" spherical coordinate system where

L_A = Boom "A" length

θ_A = Boom "A" elevation measured from Orbiter + Z-axis

ϕ_A = Boom "A" azimuth measured from Orbiter + X-axis positive about Z.

x, y, z

Cartesian coordinate system fixed in Boom "B" with origin at boom tip where;

z-axis is positive outward along Boom "B".

x & y axes are normal to z forming a rectangular right-handed system.

xyz coincides with Orbiter XYZ when $L_B = \theta_B = \phi_B = 0$

Ω, χ, Ψ

Eulerian angles specifying platform orientation.

Ω = Inclination angle positive about an axis in the platform plane coinciding with the line of nodes.


χ = Angle between line of nodes and a fixed axis in the plane normal to the Boom "A". Positive about outward boom axis.

Ψ = Angle between line-of-nodes and a fixed axis in the platform plane.

6.1.4 FLOWCHARTS AND DISPLAY FORMATS FOR THE
WAVE TRANSMISSION EXPERIMENT

10 FUNCTIONAL DESCRIPTION


This flowchart, together with 90, shows the principal functional blocks into which the Wave Transmission Experiment has been broken down.



20: WAVE TRANSMISSION EXPERIMENT DISPLAY	ERROR MSG.	
0: PROCEDURES UP TO PLASMA PHYSICS CHOICE DISPLAY	UP/I/D	8: CYL. EL. PROBE SETUP I/D
1: W. T. INSTRUMENTS ON/OFF	ON/OFF	9: FLUXGATE MAGNETOMETER SETUP I/D
	READY	10: ELECTRIC FIELD RECEIVER SETUP I/D
2: SPARE		11: MAGNETIC FIELD RECEIVER SETUP I/D
3: INITIALIZATION OF ASTRONOMY AND ORBIT MECHANICS	I/D	12: TRANSMITTER SETUP I/D
4: CURRENT VALUE OF ASTRONOMY AND ORBIT MECHANICS	I/D	13: WAVE TRANSMISSION EXPERIMENT E ² DATA I/D
5: BOOM B SETUP	I/D	14: WAVE TRANSMISSION EXPERIMENT B ² DATA I/D
6: BOOM A SETUP	I/D	
7: PLATFORM SETUP	I/D	


21 FUNCTIONAL DESCRIPTION

This flowchart shows the preliminary processing performed to determine whether the commands entered via the MFDS Keyboard are legal or not. It also shows the processing of two commonly used commands. In the Symbol XX:D, the XX stands for any entry number used by the operator.




30 FUNCTIONAL DESCRIPTION

This flowchart shows the processing to simulate the warm-up time due to switching the electronic equipment associated with this experiment on or off. The interrupt due to warmup complete can have a low priority, since a few seconds more warmup time will not affect the results of the experiment significantly.



60 FUNCTIONAL DESCRIPTION

This chart shows the functions required to activate and display the set-up of Boom "B" for the WT experiment. The desired Boom "B" tip coordinates are entered by 3:, 4:, and 5: and boom motion initiated by entry in 7:. Current coordinates can be monitored on the display, however, changing the display does not halt the computation. Upon close-out of the "desired minus actual" errors, the READY display is activated.



ORIGINAL PAGE IS
OF POOR QUALITY

600 BOOM B SETUP DISPLAY		ERROR MSG.		BOOM B CONTROL MODES	
0: PROCEDURES & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT DISPLAY	UP/I	8: SPARE			
1: BOOM B	ON/OFF	9: MANUAL CONTROL MODE	AC/3		
2: SPARE	READY	10: TRANSMITTING ANTENNA PARALLEL TO E ₁ (AUTOMATIC)	NO/I		
BOOM B POSITION					
	DESIRED	ACTUAL			
3: LENGTH		XX.X METERS			
4: ELEVATION		XX DEG FROM ORBITER #Z			
5: AZIMUTH		XXX DEG FROM ORBITER +X			
6: SPARE					
7: MOVE BOOM TO DESIRED POSITION		GO/STOP			


ORIGINAL PAGE IS
OF POOR QUALITY

601 BOOM B SETUP DISPLAY (DEFAULT VALUES)		ERROR MSG	
		BOOM B CONTROL MODES	
0: PROCEDURES & ENTRY INSTRUCTIONS UP TO BOOM B SETUP DISPLAY	UP/1	8: SPARE	
1: BOOM B	ON ON/OFF	9: MANUAL CONTROL MODE	NO NO/I
	READY	10: TRANSMITTING ANTENNA PARALLEL TO B _T (AUTOMATIC)	NO NO/I
2: SPARE			
BOOM B POSITION			
	DESIRED	ACTUAL	
3: LENGTH	50.0		XX.X METERS
4: ELEVATION	30.		XX. DEC FROM ORBITER +Z
5: AZIMUTH	0.		XXX. DEG FROM ORBITER +X
6: SPARE			
7: MOVE BOOM TO DESIRED POSITION	GO GO/STOP		

630 FUNCTIONAL DESCRIPTION


This chart is an expansion of the functions required, under the "Boom B Set-Up" routine, to orient Boom "B" to the desired length, azimuth and elevation. Current values of these parameters are checked each cycle until all three are at the desired value, within a specified tolerance. The boom motion is then stopped and a "READY" flag is set.

Note that an anti-collision or "safety" computation, as yet undefined, is performed with each change in boom coordinates.



70 FUNCTIONAL
DESCRIPTION

This chart shows the functions required to activate and display the setup of Boom A for the WT experiment. The desired Boom A tip coordinates are entered by 3:, 4:, and 5: and boom motion initiated by entry in 7:. Current coordinates can be monitored on the display, however, changing the display does not halt the computation. Upon close-out of the "desired minus actual" errors, the READY display is activated.



ORIGINAL PAGE IS
OF POOR QUALITY

700 BOOM A SETUP DISPLAY		ERROR MSG.		BOOM A CONTROL MODES	
0: PROCEDURES & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT DISPLAY		UP/I		8: SPARE	
1: BOOM A		ON/OFF		9: MANUAL CONTROL MODE	
2: SPARE		READY		10: RECEIVING DIPOLE ANTENNA PARALLEL TO BT (AUTOMATIC)	
3: LENGTH		XX.X METERS			
4: ELEVATION		XX DEG FROM ORBITER + Z			
5: AZIMUTH		XXX DEG FROM ORBITER + X			
6: SPARE					
7: MOVE BOOM TO DESIRED POSITION		GO/STOP			


701 BOOM A SETUP DISPLAY (DEFAULT DISPLAY)		ERROR MSG.		BOOM A CONTROL MODES	
0:	PROCEDURES & ENTRY INSTRUCTIONS UP TO BOOM A SETUP DISPLAY	UP/I		8:	SPARE
1:	BOOM A	ON	ON/OFF	9:	MANUAL CONTROL MODE
		<input type="checkbox"/>	READY	10:	RECEIVING DIPOLE ANTENNA PARALLEL TO BT (AUTOMATIC)
2:	SPARE				
BOOM A POSITION					
	DESIRED	ACTUAL			
3:	LENGTH	50.0	<input type="text"/>	XX.X METERS	
4:	ELEVATION	30.	<input type="text"/>	XX. DEG FROM ORBITER +Z	
5:	AZIMUTH	180.	<input type="text"/>	XXX. DEG FROM ORBITER +X	
6:	SPARE				
7:	MOVE BOOM TO DESIRED POSITION	GO	GO/STOP		

ORIGINAL PAGE IS
OF POOR QUALITY

730 FUNCTIONAL DESCRIPTION:

This chart is an expansion of the functions required, under the "Boom A Set-Up" routine, to orient Boom "A" to the desired length, azimuth and elevation. Current values of these parameters are checked each cycle until all three are at the desired value, within a specified tolerance. The boom motion is then stopped and a "READY" flag is set.

Note that an anti-collision or "safety" computation, as yet undefined, is performed with each change in boom coordinates.



80 FUNCTIONAL
DESCRIPTION:

This chart shows the functions required to activate and display the set-up of the gimbaled platform on the tip of Boom "A". The desired platform orientation (Inclination Ω , Right Ascension ψ , and Line of Nodes X) is entered by 3:, 4:, and 5: and platform motion initiated by 7:. Current values of these parameters can be monitored on the display, however, changing the display does not halt the angle computations. Upon close-out of the "desired minus actual" errors, the READY display is activated.



810 PLATFORM SETUP DISPLAY

ERROR MSG:

0: PROCEDURES & ENTRY INSTRUCTIONS
UP TO WAVE TRANSMISSION
EXPERIMENT

UP/I/D

PLATFORM CONTROL MODES

1: PLATFORM MOVE CONTROL

ON/OFF

8: SPARE

9: MANUAL CONTROL MODE

NO/I

2: SPARE

READY

10: RECEIVING DIPOLE ANTENNA
PARALLEL TO B_T (AUTOMATIC)

NO/I

PLATFORM ORIENTATION

DESIRED | ACTUAL

3: INCLINATION Ω XX DEG FROM BOOM \hat{x}_3'

4: RIGHT ASC ψ XX DEG FROM LN

5: LINE OF NODES X XX DEG FROM BOOM \hat{x}_1'

6: SPARE

7: MOVE PLATFORM TO DESIRED
ORIENTATION

GO/STOP

811 PLATFORM SETUP DISPLAY
(DEFAULT VALUES)

ERROR MSG:

0: PROCEDURES & ENTRY INSTRUCTIONS
UP TO PLATFORM SETUP
DISPLAY

UP/I/D

PLATFORM CONTROL MODES

8: SPARE

1: PLATFORM MOVE CONTROL

ON ON/OFF

9: MANUAL CONTROL MODE

NO NO/I

READY

10: RECEIVING DIPOLE ANTENNA
PARALLEL TO B_I (AUTOMATIC)

NO NO/I

2: SPARE

PLATFORM ORIENTATION

DESIRED ACTUAL

3: INCLINATION Ω 0 XX DEG FROM BOOM \hat{x}_3'

4: RIGHT ASC ψ 0 XX DEG FROM LN

5: LINE OF NODES χ 0 XX DEG FROM BOOM \hat{x}_1'

6: SPARE


7: MOVE PLATFORM TO DESIRED
ORIENTATION

GO GO/STOP

820 FUNCTIONAL DESCRIPTION


This chart is an expansion of the functions required, under the "Platform Setup" routine, to orient the platform to the desired angular orientation with regard to the Line of Nodes and Inclination. The Euler angles Ω , χ , Ψ , are checked each cycle until all three are at the pre-set desired value, within a specified tolerance. Platform motion is then stopped and the "Platform Ready" flag is set.

Note that a "Platform Safe Orientation" computation, as yet unidentified, is performed each cycle after changing the platform angles.




90 FUNCTIONAL DESCRIPTION

See Flowchart 10.



100 FUNCTIONAL DESCRIPTION

This flowchart shows the processing of the set up of the cylindrical electron probe instrument, including checks on probe sweep and current vs. voltage relationship. This flow also shows checks made preliminary to processing the electron density background measurements and recording of these measurements. These latter two functions are stubbed. However, a default value is provided in the output displays where electron density is used.



1010 CYLINDRICAL ELECTRON PROBE SETUP DISPLAY		ERROR MSG.	
0: PROCEDURES & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT DISPLAY		UP/1/D	9: DISPLAY CURRENT VS. VOLTAGE 1/NO
1: PROBE		ON/OFF	10: RECORD SETTINGS/BACKGROUND DATA GO/STOP
2: SPARE		<input type="checkbox"/> READY	11: COMPUTE ELECTRON BACKGROUND PARAMETERS YES/NO
3: SPARE			ELECTRON TEMPERATURE DEG K
4: SPARE			ELECTRON VOLTS eV
5: SPARE			ELECTRON DENSITY n_e e/m^3
6: SPARE			
7: DISPLAY SWEEP VOLTAGE		I/NO	
ANGLE BETWEEN PROBE AXIS & ORBITER VELOCITY γ			
8: COMPUTE ANGLE		DEGREES	YES/NO

1011 CYLINDRICAL ELECTRON PROBE SETUP DISPLAY (DEFAULT VALUES)		ERROR MSG:	
0: PROCEDURES & ENTRY INSTRUCTIONS UP TO CYLINDRICAL ELECTRON PROBE SETUP DISPLAY	UP/I	9: DISPLAY CURRENT VS. VOLTAGE	NO I/NO
1: PROBE	ON ON/OFF <input type="checkbox"/> READY	10: RECORD SETTINGS/BACKGROUND DATA	STOP GO/STOP
2: SPARE		11: COMPUTE ELECTRON BACKGROUND PARAMETERS	YES YES/NO
3: SPARE		ELECTRON TEMPERATURE	<input type="text" value="1161"/> DEG K
4: SPARE		ELECTRON VOLTS	<input type="text" value="0.1"/> eV
5: SPARE		ELECTRON DENSITY n_e	<input type="text" value="3.0E11"/> e/m^3
6: SPARE			
7: DISPLAY SWEEP VOLTAGE	NO I/NO		
<input type="text" value="ANGLE BETWEEN PROBE AXIS & ORBITER VELOCITY V"/>			
8: COMPUTE ANGLE	<input type="text" value="90"/> DEGREES	YES/NO	

1040 CYLINDRICAL ELECTRON PROBE
VOLTAGE VERSUS TIME

ERROR MSG:

0: PROCEDURE

UP TO CYL. EL. PROBE SETUP DISPLAY

UP/1


PROBE
VOLTAGE
IN VOLTS

1.0
0.8
0.6
0.4
0.2
0.0
-0.2
-0.4
-0.6
-0.8
-1.0

TIME IN MILLISECONDS

0
50
100
150

87



1050 CYLINDRICAL ELECTRON PROBE
CURRENT VERSUS VOLTAGE


ERROR MSG:

0: PROCEDURE

UP TO CYL. EL. PROBE SETUP DISPLAY


UP/1

CURRENT
IN NANOMIPS




1060 FUNCTIONAL DESCRIPTION

This flowchart shows the probe angle calculation. In the Wave Transmission experiment the normal probe orientation would be at 90° to the velocity vector. If $\cos Q$ is greater than .985 (10°) a very large error (80°) has been made.



110 FUNCTIONAL DESCRIPTION

This flowchart shows the processing of the setup of the triaxial fluxgate magnetometer, including its initialization constants. This flow also shows the processing necessary for making background measurements and recording of the background data. Default values assume that the magnetometer is perfectly lined up with the Y coil perpendicular to the earth's magnetic field.



ORIGINAL PAGE IS
OF POOR QUALITY

1110 FLUXGATE MAGNETOMETER SETUP DISPLAY

ERROR MSG:

0: PROCEDURE & ENTRY INSTRUCTIONS
UP TO WAVE TRANSMISSION
EXPERIMENT DISPLAY

UP/I/D

14: SPARE

1: MAGNETOMETER

ON/OFF

15: TAKE DATA

TIMES PER CYCLE

16: AVERAGE OVER

CYCLES

READY

17: BACKGROUND MEASUREMENTS

GO/STOP

2: SPARE

COIL BIAS, SCALE FACTOR, BANDPASS

3: SPARE

4: SPARE

5: SPARE

6: SPARE

7: SPARE

8: SPARE

9: SPARE

10: SPARE

11: SPARE

12: SPARE

13: SPARE

BACKGROUND B-FIELD VALUES

BX _____ GAUSS

BY _____ GAUSS

BZ _____ GAUSS

BT _____ GAUSS

CYCLOTRON FREQ. _____ KHz

18: RECORD BACKGROUND

GO/STOP

1111 FLUXGATE MAGNETOMETER SETUP DISPLAY
(DEFAULT VALUES)

ERROR MSG:

0: PROCEDURE & ENTRY INSTRUCTIONS
UP TO FLUXGATE MAGNETOMETER
SETUP DISPLAY

UP/I/D

14: SPARE

1: MAGNETOMETER

ON

ON/OFF

15: TAKE DATA

10

TIMES PER CYCLE

16: AVERAGE OVER

1

CYCLES

17: BACKGROUND MEASUREMENTS

GO

GO/STOP

2: SPARE

COIL BIAS, SCALE FACTOR, BANDPASS

3: SPARE

4: SPARE

5: SPARE

6: SPARE

7: SPARE

8: SPARE

9: SPARE

10: SPARE

11: SPARE

12: SPARE

13: SPARE

BACKGROUND B-FIELD VALUES

BX 0 GAUSS

BY 25997 GAUSS

BZ 0 GAUSS

BTOT 25997 GAUSS

CYCLOTR. FREQ. 840 KHz

18: RECORD BACKGROUND


STOP

GO/STOP

ORIGINAL PAGE IS
OF POOR QUALITY

1160 FUNCTIONAL DESCRIPTION

This flowchart shows the processing involved in calculating field measurements in the X, Y and Z coils of the magnetometer, if the B_T vector makes an arbitrary angle to the platform. When Boom A or platform is moved angularly the effect of this rotation will show in the magnetometer components measurements B_X , B_Y , B_Z via the processing defined here.



This flowchart shows the processing of the setup of the electric field receiver. Radio-frequency signals are processed in special purpose equipment outside of the computer. The computer, however turns this equipment on and off and protects the receiver against inadvertent damage by setting the gain to a minimum value when it is turned on, connected to the antenna or the receiver frequency is changed. However, this protection is not present when the amplifier gain control is reset by the experimenter. The computer can only record the instrument settings. The computer also can process a derived quantity E^2 . However, this quantity is processed on other flowcharts.



ORIGINAL PAGE IS
OF POOR QUALITY


1210 ELECTRIC FIELD RECEIVER SETUP DISPLAY		ERROR MSG:	
0: PROCEDURE & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT DISPLAY	UP/I/D	11: CONNECT RECEIVER TO ANTENNA	YES/NO
1: RECEIVER	ON/OFF	12: UPPER FREQUENCY < 30 MHz	XX.XX MHz
	READY	13: LOWER FREQUENCY > 2.9 MHz	XX.XX MHz
2: SPARE		14: ROLLOFF	SQU/LIN/EXP
3: CALIBRATION		15: SPECIAL CRT RECEIVER OUTPUT DISPLAY	ON/OFF
4: CALIBRATION		16: SET AMPLIFIER GAIN	XX.db 0 70 80 db
5: CALIBRATION		17: RECORD INSTRUMENT SETTINGS AND BACKGROUND	GO/STOP
6: BIAS		18: DISPLAY ANGLE θ_T TO DIPOLE ANTENNA AXIS	YES/NO
7: BIAS		RB =	DEGREES
8: BIAS			
9: SCALE FACTOR			
10: SCALE FACTOR			

ORIGINAL, PAGE 18
OF FOUR QUALITY

12: ELECTRIC FIELD RECEIVER SETUP DISPLAY (DEFAULT VALUES)		ERROR MSG.		
0: PROCEDURE & ENTRY INSTRUCTIONS UP TO ELECTRIC FIELD RECEIVER SETUP DISPLAY	UP/D	11: CONNECT RECEIVER TO ANTENNA	YES	YES/NO
1: RECEIVER	ON	12: UPPER FREQUENCY < 30 MHz	30.50	XX-XX-MHZ
	ON/OFF	13: LOWER FREQUENCY > 3.9 MHz	3.50	XX-XX-MHZ
	READY	14: ROLLOFF	EXP	SQU/LTV/EXP
2: SPARE		15: SPECIAL CRT RECEIVER OUTPUT DISPLAY	ON	ON/OFF
3: CALIBRATION		16: SET AMPLIFIER GAIN	40	XX-dB 0 TO 80 dB
4: CALIBRATION		17: RECORD INSTRUMENT SETTINGS AND BACKGROUND	STOP	GO/STOP
5: CALIBRATION		18: DISPLAY ANGLE BT TO DIPOLE ANTENNA AXIS	YES	YES/NO
6: BIAS		R8 =	0	DEGREES
7: BIAS				
8: BIAS				
9: SCALE FACTOR				
10: SCALE FACTOR				

130 FUNCTIONAL DESCRIPTION

This flowchart shows the processing of the setup of the magnetic field receiver. Radio-frequency signals are processed in special purpose equipment outside of the computer. The computer, however turns this equipment on and off and protects the receiver against inadvertent damage by setting the gain to a minimum value when it is turned on, connected to the antenna, or the receiver frequency is changed. However, this protection is not present when the amplifier gain control is reset by the experimenter. The computer can only record the instrument settings. The computer also can process a derived quantity B^2 . However, this quantity is processed on other flowcharts.




1310 MAGNETIC FIELD RECEIVER SETUP DISPLAY		ERROR MSG.	
0: PROCEDURE & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT DISPLAY	UP/I/D	11: CONNECT RECEIVER TO ANTENNA	YES/NO
1: RECEIVER	ON/OFF	12: UPPER FREQUENCY < 30 MHz	XX.XX MHz
	READY	13: LOWER FREQUENCY > 3.9 MHz	XX.XX MHz
2: SPARE		14: ROLLOFF	SQV/LIN/EXP
3: CALIBRATION		15: SPECIAL CRT RECEIVER OUTPUT DISPLAY	ON/OFF
4: CALIBRATION		16: SET AMPLIFIER GAIN	XX db 0 TO 80 db
5: CALIBRATION		17: RECORD INSTRUMENT SETTINGS AND BACKGROUND	GO/STOP
6: BIAS		18: DISPLAY ANGLE θ_T TO THE NORMAL TO THE LOOP ANTENNA	YES/NO
7: BIAS		LB =	DEGREES
8: BIAS			
9: SCALE FACTOR			
10: SCALE FACTOR			

1311 MAGNETIC FIELD RECEIVER SETUP DISPLAY (DEFAULT VALUES)			ERROR MSG:	
0:	PROCEDURE & ENTRY INSTRUCTIONS UP TO MAGNETIC FIELD RECEIVER SETUP DISPLAY		UP/I/D	11: CONNECT RECEIVER TO ANTENNA <u>YES</u> YES/NO
				12: UPPER FREQUENCY < 30 MHz <u>20.50</u> XX.XX MHz
1:	RECEIVER <u>ON</u>	ON/OFF		13: LOWER FREQUENCY > 3.9 MHz <u>3.90</u> XX.XX MHz
	<u>READY</u>			14: ROLLOFF <u>EXP</u> SQU/LIN/EXP
2:	SPARE			15: SPECIAL CRT RECEIVER OUTPUT <u>ON</u> ON/OFF
3:	CALIBRATION			16: SET AMPLIFIER GAIN <u>40</u> XX.db
4:	CALIBRATION			0 TO 80 db
5:	CALIBRATION			17: RECORD INSTRUMENT SETTINGS <u>STOP</u> GO/STOP
6:	BIAS			18: DISPLAY ANGLE BT TO THE NORMAL <u>YES</u> YES/NO
7:	BIAS			TO THE LOOP ANTENNA
8:	BIAS		LB = <u>90</u> DEGREES	
9:	SCALE FACTOR			
10:	SCALE FACTOR			

140 FUNCTIONAL DESCRIPTION

This flowchart shows the processing in setting up the transmitter. Whenever a transmitter setting change is made, the attenuator is set to its maximum value to protect other equipment. However, the experimenter can reset the attenuator to a lower attenuation and this reset is not protected. This flowchart also incorporates the adjustment of the (33 meters max.) antenna length which may be connected to the transmitter. In addition to the attenuator, the experimenter can set a signal level ratio ($S^2 \leq 1$) which affects the maximum power that the transmitter is allowed to radiate for this experiment.



ORIGINAL PAGE IS
OF POOR QUALITY

TRANSMITTER SETUP DISPLAY		ERROR MSG:		ANTENNA		READY
0:	PROCEDURES & ENTRY INSTRUCTIONS		UP/I/O			
1:	TRANSMITTER		ON/OFF			
2:	SPARE		READY			
3:	SET SIGNAL LEVEL RATIO S ²		X.XX			
4:	CONNECT ANTENNA TO TRANSMITTER		YES/NO			
5:	TRANSMITTER WAVEFORM		SIN/SQ/SPECIAL			
6:	SET TRANSMITTER FREQUENCY F		XX.XX MHz			
7:	TRANSMITTER TRANSMISSION		GO/STOP			
8:	SET TRANSMITTER ATTENUATOR		XX		0 TO 80 db	
9:	SET WAVE GENERATOR ANTENNA LENGTH		XX.X		METERS	
10:	ANTENNA LENGTH		GO/STOP			


TRANSMITTER SETUP DISPLAY (DEFAULT VALUES)		ERROR MSG:
0: PROCEDURES & ENTRY INSTRUCTIONS	UP/I/D	
1: TRANSMITTER	ON	ON/OFF
2: SPARE		READY
3: SET SIGNAL LEVEL RATIO S ²	1.00	X-XX
4: CONNECT ANTENNA TO TRANSMITTER	YES	YES/NO
5: TRANSMITTER WAVEFORM	SIN	SIN/SQU/SPECIAL
6: SET TRANSMITTER FREQUENCY f	19.60	XX.XX MHZ
7: TRANSMITTER TRANSMISSION	GO	GO/STOP
8: SET TRANSMITTER ATTENUATOR	80	XX 0 TO 80 db
9: SET WAVE GENERATOR ANTENNA LENGTH	6.0	XX.X METERS
10: ADJUST ANTENNA LENGTH	GO	GO/STOP

ORIGINAL PAGE IS
OF POOR QUALITY

READY


1460 FUNCTIONAL DESCRIPTION

This flowchart shows the processing to adjust the antenna length to a new value. The interrupt when the antenna is ready can have a low priority, since a few seconds more on antenna length readiness will not significantly influence the experiment operation.



150 FUNCTIONAL DESCRIPTION

This flowchart shows the processing especially adapted to rapid performance of the Wave Transmission experiment. Instead of separately setting up transmitter and receiver, they are adjusted here with reference to a single display either manually, or via an automatic sequence depending on 12:YES or 12:NO. The processing on this flowchart is experiment specific and is partially redundant with that of previous Transmitter and Receiver setup charts. Infrequently changed settings such as roll-off characteristics must be reset using those setup charts.




1510 WAVE TRANSMISSION EXPERIMENT E ² SETUP DISPLAY		ERROR MSG:		MANUAL & AUTOMATIC MODE	
0:	PROCEDURE & ENTRY INSTRUCTIONS UP TO WAVE TRANSMISSION EXPERIMENT E ² SETUP DISPLAY		UP/I/D	8:	SPECIAL RECEIVER CRT DISPLAY ON/OFF
1:	ALL EXPERIMENT INSTRUMENTS		ON/OFF	9:	E ² DATA ACQUISITION DISPLAY I
			READY	10:	SPARE
2:	SPARE			11:	SPARE
3:	SPARE				
	MANUAL MODE			12:	AUTOMATIC FREQUENCY SEQUENCE YES/NO
4:	SET TRANSMITTER FREQUENCY		XX.XX MHz	13:	AUTOMATIC RECEIVER BANDWIDTH FREQUENCY ± X.XX MHz
5:	SET RECEIVER UPPER FREQUENCY		XX.XX MHz	14:	SPARE
6:	SET RECEIVER LOWER FREQUENCY		XX.XX MHz		
7:	SPARE				

1511 WAVE TRANSMISSION EXPERIMENT E^2 SETUP DISPLAY (DEFAULT VALUES)			ERROR MSG:
0: PROCEDURE & ENTRY INSTRUCTIONS			UP/I/D
UP TO WAVE TRANSMISSION EXPERIMENT E^2 SETUP DISPLAY			
1: ALL EXPERIMENT INSTRUMENTS	ON	ON/OFF	
		READY	
2: SPARE			
3: SPARE			
MANUAL MODE			
4: SET TRANSMITTER FREQUENCY	19.50	XX.XX MHz	
5: SET RECEIVER UPPER FREQUENCY	19.61	XX.XX MHz	
6: SET RECEIVER LOWER FREQUENCY	19.59	XX.XX MHz	
7: SPARE			
MANUAL & AUTOMATIC MODE			
8: SPECIAL RECEIVER CRT DISPLAY	ON	ON/OFF	
9: E^2 DATA ACQUISITION DISPLAY	1	1	
10: SPARE			
11: SPARE			
12: AUTOMATIC FREQUENCY SEQUENCE			YES YES/NO
13: AUTOMATIC RECEIVER BANDWIDTH FREQUENCY \pm			0.01 X.XX MHz
14: SPARE			

1550 FUNCTIONAL DESCRIPTION


This flowchart shows the processing of the mean square electric field values received by the computer. If the computer is in the automatic (frequency sequencing) mode the planned Wave Transmission experiment sequence can be completed using this flowchart only. If the manual mode is selected, the experimenter must back up to the previous (1510) display to set each new frequency.



NOTE: ROLL-OVER OF DISPLAY
TIME AXIS IS REQUIRED

1560 FUNCTIONAL DESCRIPTION


In implementing the display "roll over" of the time axis is required. There are many ways to do this, the important point is that after the first ten seconds of the experiment, there should always be at least ten seconds of data history showing, even if the experiment lasts longer than 40 seconds. The display shown is idealized in that the fall of E^2 to near-zero when the transmitter attenuator is set to its maximum value when changing frequencies is not shown, nor rise in E^2 during the resetting of the attenuator by the experimenter.



FOLDOUT FRAME /

FOLDOUT FRAME


NOTE: ROLL-OVER OF DISPLAY
TIME AXIS IS REQUIRED.



1580 FUNCTIONAL DESCRIPTION

This flowchart presents the arithmetic operations involved in calculating \bar{E}^2 , r , ω_p and Cyclotron Frequency (stub) that are displayed on 1560.


ORIGINAL PAGE IS
OF POOR QUALITY



160 FUNCTIONAL DESCRIPTION

This flowchart shows the processing especially adapted to rapid performance of the Wave Transmission experiment. Instead of separately setting up transmitter and receiver, they are adjusted here with reference to a single display either manually, or via an automatic sequence depending on 12:YES or 12:NO. The processing on this flowchart is experiment specific and is partially redundant with that of previous Transmitter and Receiver setup charts. Infrequently changed settings such as roll-off characteristics must be reset using those setup charts.

ORIGINAL PAGE IS
OF POOR QUALITY



1610 WAVE TRANSMISSION EXPERIMENT B ² SETUP DISPLAY		ERROR MSG:																			
0: PROCEDURE & ENTRY INSTRUCTIONS		UP/I/D																			
UP TO WAVE TRANSMISSION EXPERIMENT B ² SETUP DISPLAY																					
1: ALL EXPERIMENT INSTRUMENTS		ON/OFF																			
				READY																	
2: SPARE																					
3: SPARE																					
4: SET TRANSMITTER FREQUENCY		XX XX MHz																			
5: SET RECEIVER UPPER FREQUENCY		XX XX MHz																			
6: SET RECEIVER LOWER FREQUENCY		XX XX MHz																			
7: SPARE																					

1611 WAVE TRANSMISSION EXPERIMENT B²

SETUP DISPLAY
(DEFAULT VALUES)

ERROR MSG:

MANUAL & AUTOMATIC MODE

0: PROCEDURE & ENTRY INSTRUCTIONS

UP/I/D

UP TO WAVE TRANSMISSION EXPERIMENT B²
SETUP DISPLAY

8: SPECIAL RECEIVER CRT DISPLAY

ON

ON/OFF

1: ALL EXPERIMENT INSTRUMENTS

ON

ON/OFF

9: B² DATA ACQUISITION DISPLAY

I

I

10: SPARE

READY

11: SPARE

2: SPARE

3: SPARE

MANUAL MODE

12: AUTOMATIC FREQUENCY SEQUENCE

YES

YES/NO

4: SET TRANSMITTER FREQUENCY

19.60 XX.XX MHz

13: AUTOMATIC RECEIVER BANDWIDTH
FREQUENCY ±

0.01

X.XX MHz

5: SET RECEIVER UPPER FREQUENCY

19.61 XX.XX MHz

14: SPARE

6: SET RECEIVER LOWER FREQUENCY

19.59 XX.XX MHz

7: SPARE

ORIGINAL PAGE IS
OF POOR QUALITY

1611 WAVE TRANSMISSION EXPERIMENT B²
SETUP DISPLAY
(DEFAULT VALUES)

ERROR MSG:

MANUAL & AUTOMATIC MODE

0: PROCEDURE & ENTRY INSTRUCTIONS

UP/I/D

UP TO WAVE TRANSMISSION EXPERIMENT B²
SETUP DISPLAY

8: SPECIAL RECEIVER CRT DISPLAY ON ON/OFF

1: ALL EXPERIMENT INSTRUMENTS

ON

ON/OFF

9: B² DATA ACQUISITION DISPLAY I I

READY

10: SPARE

11: SPARE

2: SPARE

3: SPARE

MANUAL MODE

12: AUTOMATIC FREQUENCY SEQUENCE YES YES/NO

4: SET TRANSMITTER FREQUENCY

19.60 XX.XX MHz

13: AUTOMATIC RECEIVER BANDWIDTH
FREQUENCY 0.01 X.XX MHz

5: SET RECEIVER UPPER FREQUENCY

19.61 XX.XX MHz

14: SPARE

6: SET RECEIVER LOWER FREQUENCY


19.59 XX.XX MHz

7: SPARE

ORIGINAL PAGE IS
OF POOR QUALITY


1650 FUNCTIONAL DESCRIPTION

This flowchart shows the processing of the mean square magnetic field values received by the computer. If the computer is in the automatic (frequency sequencing) mode the planned Wave Transmission experiment sequence can be completed using this flowchart only. If the manual mode is selected, the experimenter must back up to the previous (1610) display to set each new frequency.




1660 FUNCTIONAL DESCRIPTION

In implementing the display, "roll over" of the time axis is required. There are many ways to do this, the important point is that after the first ten seconds of the experiment, there should always be at least ten seconds of data history showing, even if the experiment lasts longer than 40 seconds. The display 1661 shown is idealized in that the temporary fall of B^2 to near zero when the transmitter attenuator is set to its maximum value is not shown, nor the rise in B^2 during the resetting of the attenuator by the experimenter.




NOTE: ROLL-OVER OF DISPLAY
TIME AXIS IS REQUIRED



1680 FUNCTIONAL DESCRIPTION

This flowchart presents the arithmetic operations involved in calculating \bar{B}^2 , r , ω_p and Cyclotron Frequency (stub) that are displayed on 1660.



6.2 PASSIVE OBSERVATIONS OF AMBIENT PLASMA EXPERIMENT

(The experiment procedure for this experiment is given in Section 3.2.2 of the Final Report.)

The key display of this experiment is Display No. 200, where the experimenter chooses the instruments he wishes to use in order to observe the plasma. Via Entry No. 3: he can initialize his orbit, which for this set of experiments is always circular. Once started, the orbit computation continues to compute needed orbital quantities every two seconds whether these are used by the experiments or not. If the experimenter wishes to see where the orbiter is, he will enter 4:1 which will bring Display 500 with complete information on the latest orbit update. Time is assumed displayed separately on a non-CRT (TDU) display.

The capability to activate all instruments is given to the experimenter by Entry No. 1:. He can manipulate the individual instrument settings via Entry No's. 8 and 9 for the cylindrical electron probe and fluxgate magnetometer, and via Entry No's. 13: through 18: for the other instruments. Entry No. 19: gives him the capability to selectively record the outputs of only those instruments data that are worth preserving. The mere fact that an instrument is on does not force the experimenter to record the data produced. The experimenter can also limit the time duration of recordings produced.

Entry No's. 10: and 11: show summary displays to the experimenter. Display 280 (Entry 10:1) shows both orbital and boom/platform summary data. Display 290 (Entry 11:1) shows summary data on the outputs of several instruments participating in this experiment and may be considered experiment specific. Note that there is physical area on this display to accommodate additional instrument outputs should this be needed, without requiring substantial additional software, since the quantities themselves that are displayed are easily available from the available individual instrument computational routines.

6.2.1 Definition of Variables

The following definitions define variables used in the flowcharting that follows. For a more comprehensive understanding of the equations involved see the main body of the Final Report.

<u>LTo</u>	Local time at the first descending node. $0 \leq LTo < 24$ HRS., keyed in HRS:MINS:SECS. on the keyboard (or initialized in the TDU) Days are not considered in this simulation.
GmTo	Greenwich Mean Time at the instant of descending node crossing of the Orbiter. Keyed in HRS:MINS:SEC. on the keyboard (or initialized in the TDU) $0 \leq GmTo < 24$ HRS.
MET _i	Mission Elapsed Time. Time since passage of the first descending node at the start of the simulation run keyed in HRS:MINS:SECS. on the keyboard (or initialized in the TDU).
τ	Time incrementing variable in seconds.
LToH	LTo expressed in decimal hours.
UToH	GmTo expressed in decimal hours.
OTS _i	MET _i expressed in seconds.
t	Time in seconds = OTS _i + duration of simulation run.
UToS	Initial value of GMT expressed in seconds.
UTS	Current value of GMT in seconds.
R	Geocentric radius of the Orbiter, in meters. $R = (R_e + H) \times 1000$.
R_e	Radius of the spherical earth, 6371 KM
H	Altitude of Orbiter above spherical earth, KM. Typical values: $120 \leq H \leq 400$.
LON	East longitude of the Orbiter with respect to Greenwich Meridian, degrees.
LAT	South latitude of Orbiter, degrees.
LT	Local Time of the Orbiter (or any other object referred to), as given by the position of the sun at that location (LT in decimal HRS for computation, HRS:MINS for display). Local time is 12:00 (noon) if the sun is in the half-plane containing the earth polar axis as boundary and the Orbiter geocentric radius.

Λ	Euler angle between the local vertical + Z^I axis and the Orbiter + Z axis $0^0 \leq \Lambda \leq 180^0$, degrees measured positive from + Z^I .
Γ	Euler angle between the vector pointing south in the horizontal plane at the Orbiter and the positive line of nodes of the Orbiter $\Lambda \Gamma \Delta$ system. $0^0 \leq \Gamma < 360^0$, degrees measured positive from + X rotating to + Y . See part III diagram of axis.
Δ	Euler angle between line of nodes and Orbiter + X axis $0^0 \leq \Delta < 360^0$.
T Orbit	Orbiter orbital period, seconds.
i	Inclination angle of orbit plane to earth's equatorial plane, degrees $0 \leq i \leq 90^0$. For a polar orbit $i = 90^0$.
w	Rate of rotation of Orbiter geocentric vector relative to an inertial coordinate frame in the plane of the orbit, in radians/sec.
λ	Angle between earth's north polar axis and orbiter geocentric radius vector measured southward from north polar axis. $0^0 \leq \lambda \leq 180^0$.
Magnetic Dip Angle	Angle between local geocentric radius vector and local earth magnetic field vector, radians (displayed in degrees).
$ B_T $	Magnitude of earth's magnetic field vector, gammas. Range 0 to 10^5 gammas, least count one gamma.
T	Neutral atmosphere temperature, degrees Kelvin Range 10^2 to 10^4 . Least count 0.1% of value.
$N(O_2^+)$,	The number of free ions per cubic meter Range: 10^6 to 10^{12} .
$N(NO^+)$,	Least count 1% of value.
$N(O^+)$	

$n(LT)$	The number of free electrons per cubic meter, expressed as a function of local time. $n(LT)$ is also a function of other variables. Range 10^6 to 10^{14} least count 1% of value. Also used for total ion density in neutral atmosphere.
P	Probe voltage in volts. Range -10^4 to $+10^4$ volts. Least count 0.1% of value.
I_e^+ (or I_e^-)	Current due to electrons flowing into probe when probe voltage positive (or negative).
I_i^- (or I_i^+)	Current due to ions flowing into probe when probe voltage is negative (or positive).
\bar{V} , \bar{V}_s	Orbiter velocity vector, meters/sec, Orbiter velocity = ωR meters/sec.
CSV	Angle between the probe axis of the cylindrical Electron Probe and the Orbiter velocity vector.
M_i	The mass of a particular ion species, i , measured in kilograms. Range 10^{-27} to 10^{-25} kg. Least count 0.1% of value.
V_e	The velocity of a particle involved in probe measurement, relative to a quasi-inertial Orbiter coordinate system in which \bar{V}_s is also measured. Range $\pm 10^4$ meters/sec. Least count one M/sec.
Lower to Upper Mass Limits	One to forty Atomic Mass Units (AMU).
$X'Y'Z'$	Quasi-inertial orbiter-centered cartesian coordinate system. Z' outward along geocentric radius, $+X'$ points South, $+Y'$ points East.

6.2.2 Typical Values for Passive Observations of Ambient Plasma Experiment Parameters

The following parameter values may be considered as typical. They could, for example, be used as default values. Additional values have been inserted on several graphical displays for illustrative purposes.

Orbiter attitude

$$\Lambda = 0 \text{ Degrees}$$

$$\Gamma = 0 \text{ Degrees}$$

$$\Delta = 0 \text{ Degrees}$$

Boom A

$$\theta = 0 \text{ Degrees}$$

$$\phi = 0 \text{ Degrees}$$

$$L_A = 0 \text{ Degrees}$$

Platform

$$\Omega = 0 \text{ Degrees}$$

$$\chi = 0 \text{ Degrees}$$

$$\psi = 0 \text{ Degrees}$$

Angle platform X_1 to Orbiter $\bar{V} = 0 \text{ Degrees}$

Inclination of Orbit Plane = 57 Degrees

Altitude $H = 300 \text{ KM}$

$|B_T| = 27183 \text{ GAMMA.}$

Densities of Ions

$$N(O^+) = 4.6 \text{ E } 11$$

$$N(O2^+) = 2.9 \text{ E } 10$$

$$N(NO^+) = 1.1 \text{ E } 10$$

Density of Electrons

$$n(\text{LT}) = 5.0 \text{ E } 11$$

Density of Neutral Particles

$$N(\text{O}) = 7.6 \text{ E } 16$$

$$N(\text{O}_2) = 7.5 \text{ E } 16$$

$$N(\text{N}_2) = 4.0 \text{ E } 17$$

$$N(\text{HE}) = 3.4 \text{ E } 13$$

$$\text{Upper Mass Limit} \quad 40 \text{ AM U}$$

$$\text{Lower Mass Limit} \quad 1 \text{ AM U}$$

$$\text{Resolution} \quad 1 \text{ AM U}$$

Planar Electron Trap

$$\text{Lower Energy Limit} \quad 1 \text{ eV}$$


$$\text{Upper Energy Limit} \quad 1000 \text{ eV}$$

$$\text{Ion Temperature} \quad 1000 \text{ Deg. Kelvin}$$

6.2.3 FLOWCHARTS AND DISPLAY FORMATS FOR THE PASSIVE OBSERVATION AMBIENT PLASMA EXPERIMENT


11 Functional Description

This flowchart, together with 91, shows the principal functional blocks into which the Passive Observation of Ambient Plasma Experiment has been broken down.




91 Functional Description
See Flowchart No. 11.

ORIGINAL PAGE IS
OF POOR QUALITY



40 Functional Description

This flowchart shows the functions required to activate and display the Astronomy/Orbit computations. Orbit computations must be stopped to re-initialize. The orbit computations can be started or stopped from this chart, without necessarily going to No. 50 (Alternative to initializing GMT and MET using the MFDS Keyboard, the MFDS special-purpose time display units (TDU) might be used).



400 INITIALIZE ASTRONOMY AND ORBIT MECHANICS DISPLAY


ERROR MSG:

0: PROCEDURES UP TO _____	UP/I/D	11: SET INITIAL GREENWICH MEAN TIME GMT _____	XX SECS
1: CALCULATE ORBIT/ASTRONOMY FUTURE PARAMETERS _____	GO/STOP	INITIAL EAST LONGITUDE _____	DEGREES
2: SPARE		12: ORBIT INCLINATION _____	XX 0° TO 90°
3: SET FIRST DESCENDING NODE TIME LT ₀ _____	XX HRS	13: ORBIT ALTITUDE _____	XXXX KM
4: SET FIRST DESCENDING NODE TIME LT ₀ _____	XX MINS	14: SPARE	
5: SET FIRST DESCENDING NODE TIME LT ₀ _____	XX SECS	15: ORBITER ATTITUDE LINE OF NODES I _____	XXX DEGREES
6: SET ELAPSED TIME MET ₁ _____	XX HRS	16: ORBITER ATTITUDE INCLINATION A _____	XX DEGREES
7: SET ELAPSED TIME MET ₁ _____	XX MINS	17: ORBITER ATTITUDE RIGHT ASC Δ _____	XXX DEGREES
8: SET ELAPSED TIME MET ₁ _____	XX SECS	18: MANUAL ATTITUDE CONTROL MODE _____	NO/I
9: SET INITIAL GREENWICH MEAN TIME GMT ₀ _____	XX HRS	19: AUTOMATIC ATTITUDE CONTROL MODE _____	NO/I
10: SET INITIAL GREENWICH MEAN TIME GMT ₀ _____	XX MINS		

420 Functional Description

This flowchart shows conversion of time quantities to decimal hours and to seconds also calculation of the East longitude of the initial descending mode.

ORIGINAL PAGE IS
OF POOR QUALITY




C.2

50 Functional Description

This flowchart shows functions needed to keep the orbit/astrometry parameters up to date. Orbit computations can be started/stopped from this chart, the experimenter can determine where he is from display 500 and how long he has until sunrise/sunset. Recording of Orbital positions and attitudes is done at start/stop of the orbit computations. (Other recording of this data is auxiliary to data collection from instruments. (see instrument below charts).

ORIGINAL PAGE 15
OF POOR QUALITY




NOTE: GMT AND MET SHOWN ON TDU MFDS DISPLAYS.

500 CURRENT VALUES OF ASTRONOMY, ORBIT MECHANICS PARAMETERS		ERROR MSG	
0: PROCEDURES UP TO		UP/T/D	ORBITER VELOCITY TOTAL
			EASTWARD
			NORTHWARD
			SOUTHWARD
1: CALCULATE ORBIT/ASTRONOMY FUTURE PARAMETERS		GO/S/STOP	
2: SPARE			
EARTH-CENTERED COORDINATES			
EAST LONGITUDE		DEGREES	ORBITER ATTITUDE
NORTH LATITUDE		DEGREES	LINE OF NODES T
SOUTH LATITUDE		DEGREES	INCLINATION A
ALTITUDE		DEGREES	RIGHT ASC A
INCLINATION		KILOMETERS	3: MANUAL ATTITUDE CONTROL
		DEGREES	4: AUTOMATIC ATTITUDE CONTROL MODE
ORBITER LOCAL TIME		HRS:MIN	5: TIME UNTIL SUNRISE
			6: TIME UNTIL SUNSET
			7: SPARE


510 Functional Description


This flowchart shows how the astronomy/orbit parameters are updated. This computation, once started, continues regardless of what other action the experimenter takes, except specifically stopping the orbit computation itself.



5101 Functional Description

See 510






5102 Functional Description

See 510

ORIGINAL PAGE IS
OF POOR QUALITY

102 Functional Description


This flowchart shows the processing of the set up of the cylindrical electron probe instrument, including a check on probe sweep. The equations of 1052 are used in the simulation and are based on theory. If an actual instrument were connected to the computer block 1072 would be used.



1015 CYLINDRICAL ELECTRON PROBE SETUP DISPLAY		ERROR MSG:	
0: PROCEDURES UP TO	UP/I/D	10: RECORD SETTINGS/BACKGROUND DATA	GO/STOP
1: PROBE	ON/OFF	11: COMPUTE ELECTRON BACKGROUND PARAMETERS	YES/NO
	READY	ELECTRON TEMPERATURE	DEGREES KELVIN
2: SPARE		ELECTRON VOLTS	VOLTS
3: SPARE		ELECTRON DENSITY n_e	PER/M ³
4: SPARE		LATITUDE LAT	DEGREES
5: SPARE		LOCAL TIME LT	HRS: MINS
6: SPARE		ANGLE PLATFORM X _p TO V	DEGREES
7: DISPLAY SWEEP VOLTAGE	I/NO	ALTITUDE H	KM.
ANGLE BETWEEN PROBE AXIS & ORBITER VELOCITY V		MAGNETIC DIP ANGLE	DEGREES
8: COMPUTE ANGLE	DEGREES YES/NO		
9: DISPLAY CURRENT VS. VOLTAGE	I/NO		

1052 Functional Description

This flowchart shows the relationship of the probe current, voltage and angle computations and the proximate displays involved.



1054 CYLINDRICAL ELECTRON PROBE
CURRENT VERSUS VOLTAGE

ERROR MSG

0: PROCEDURE

UP TO CYL. EL. PROBE SETUP DISPLAY

UP/I

ANGLE PLATFORM X, TO V

DEGREES

CURRENT
IN NANOAMPS

-1.0

-0.5

+0.5


+1.0

VOLTS

ORIGINAL PAGE IS
OF POOR QUALITY

600
500
400
300
200
100
100
200
300
400
500
600


This flowchart shows the computation of the Probe current depending on whether the Probe potential P is positive or negative. An error message will result if the probe axis points to within 10° of the velocity vector of the Orbiter. The repeated (with 1062) computation serves as a continuous check on probe angles.




ORIGINAL PAGE IS
OF POOR QUALITY

1062 Functional Description

This flowchart shows a computation of the probe angle (normally oriented near 90° to vel. vector \bar{V}) as a sub-routine. In addition a check is made to make sure that the probe axis is not pointing within 10° of parallel to \bar{V}_s - which will yield erroneous data.





112 FUNCTIONAL DESCRIPTION

112 FUNCTIONAL DESCRIPTION

This flowchart shows the processing of the setup of the triaxial fluxgate magnetometer, including its initialization constants. This flow also shows the processing necessary for making background measurements and recording of the background data.

```
graph TD
    Start([112  
FLUXGATE MAGNETOMETER  
SET-UP & BACKGROUND  
MEASUREMENT]) --> Display{1112  
FLUXGATE  
MAGNETOMETER  
SET-UP DISPLAY}
    Display --> Keyboard[/KEYBOARD ENTRY/]
    
    Keyboard -- "0:UP  
2:VALUE" --> NewProc[NEW PROCESSING  
(STUB)]
    NewProc --> End([END])
    
    Keyboard -- "1:VALUE" --> CalcOnOff[PERFORM ON/OFF  
CALCULATIONS  
SET READY FLAG]
    CalcOnOff --> Ready1{READY?}
    Ready1 -- YES --> RecordData[RECORD ROOM  
PLATFORM &  
INSTRUMENT  
DATA &  
SETTINGS  
(STUB)]
    Ready1 -- NO --> Error1[ERROR MSG]
    RecordData --> StopRec[STOP RECORDING  
(STUB)]
    StopRec --> End
    
    Keyboard -- "3:VALUE THRU  
14:VALUE" --> Calib[BALIBRATE BIAS AND  
SCALING CONSTANTS  
INITIALIZE GYRO PASS  
CONSTANTS  
(STUB)]
    Calib --> Ready2{READY?}
    Ready2 -- YES --> SmoothCalc[BACKGROUND DATA  
SMOOTHING CALCULATION  
(STUB)]
    Ready2 -- NO --> Error2[ERROR MSG]
    SmoothCalc --> CalcBg[192  
CALCULATE Bx, By, Bz  
BACKGROUND FIELD VALUES]
    CalcBg --> End
    
    Keyboard -- "15:VALUE  
16:VALUE" --> InitRate[INITIALIZE DATA SAMPLING RATE  
AND SMOOTHING TIME  
(STUB)]
    InitRate --> Ready3{READY?}
    Ready3 -- YES --> SmoothCalc
    Ready3 -- NO --> Error3[ERROR MSG]
    SmoothCalc --> CalcBg
    
    Keyboard -- "18:VALUE" --> GoStop1{GO/STOP}
    GoStop1 -- GO --> Ready4{READY?}
    Ready4 -- YES --> RecordData
    Ready4 -- NO --> Error4[ERROR MSG]
    GoStop1 -- STOP --> End
```


1112 FLUXGATE MAGNETOMETER SETUP DISPLAY

ERROR MSG:

0: PROCEDURE & ENTRY INSTRUCTIONS
UP TO

UP/I/D

14: SPARE

1: MAGNETOMETER

ON/OFF

15: TAKE DATA

TIMES PER CYCLE

16: AVERAGE OVER

CYCLES

READY

17: BACKGROUND MEASUREMENTS

GO/STOP

2: SPARE

COIL BIAS, SCALE FACTOR, BANDPASS

3: SPARE

4: SPARE

5: SPARE

6: SPARE

7: SPARE

8: SPARE

9: SPARE

10: SPARE

11: SPARE

12: SPARE

13: SPARE

ORIGINAL PAGE IS
OF POOR QUALITY

BACKGROUND B-FIELD VALUES


BX		GAMMA
BY		GAMMA
BZ		GAMMA
BT		GAMMA

18: RECORD BACKGROUND DATA AND
INSTRUMENT SETTING

GO/STOP

190 Functional Description


This flowchart shows a sub-routine for the computations of the Absolute Temperature T in the neutral atmosphere model. Auxiliary quantities computed are solar hour angle (SHA) and an angle τ which represents a lag in density relative to local time at any point in the atmosphere.



Functional Description

This flowchart shows a subroutine for the computation of the X' and Y' components of the earth's magnetic field. Since the axis of symmetry of the magnetic field is along the geographical earth polar axis, $BY'=0$. B_T is also computed.

Finally, BX , BY and BZ are computed based on orbiter, boom and platform orientations via a very general transformation 223 and 223.5.




This flowchart shows a subroutine for the computation of the Density of Neutral particles of four different species.




Functional Description

This flowchart shows the computations of the electron density subroutine. Values of $n(LT)$ are based on several empirical equations each valid in its own range of latitude, altitude and local time.




Functional Description

This flowchart shows a subroutine to compute values of F, the ion density. Values of F are based on empirical equations, each valid within a specific altitude range. Ion densities are assumed proportional to the local electron density $n(LT)$.




210 Functional Description

This flowchart shows both the setup of and data processing by the Rubidium Magnetometer.




NOTE: ROLLOVER OF THE TIME AXIS IS REQUIRED FOR THIS DISPLAY




220 Functional Description


This flowchart shows the processing of the setup of the spherical ion probe instrument. To measure Ions it always operates in the Electron rejection mode. In addition to checking Probe Voltage sweep vs. time, two operating displays are planned for - (1) Probe current vs. voltage is stubbed, (2) Log Probe current vs. voltage is computed (2230).



2210 Functional Description

This flowchart shows the relationship of the Probe Voltage vs. Time computation to the proximate displays involved.






This flowchart shows the relationship of the log current vs. Voltage computation to the proximate displays involved.



NOTE: ANGLE




2237 Functional Description

This flowchart shows the computation of Ion current versus Voltage based on calculated temperatures 190, electron densities 199, and average ion densities 203. This calculation requires availability of the error function integral

$$\theta(X) = \frac{2}{\sqrt{\pi}} \int_0^X e^{-t^2} dt \text{ as a subroutine.}$$


ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE 19
OF POOR QUALITY

230 Functional Description

This flowchart shows the computations involved in setting up the Ion Mass Spectrometer and computing the response of this instrument 2330, 2350 on a simulated basis to the ion densities encountered.



2300 ION MASS SPECTROMETER SETUP DISPLAY


ERROR MSG:

0: PROCEDURE UP TO	UP/I/O	9: RECORD INSTRUMENT SETTINGS AND DATA	60/STOP
1: ION MASS SPECTROMETER	ON/OFF		
2: SPARE	READY		
3: SET LOWER MASS LIMIT	XX AMU		
4: SET UPPER MASS LIMIT	XX AMU		
5: SET RESOLUTION	XX AMU		
6: SPARE			
7: DISPLAY ION CURRENT VS MASS	I/NO		
8: DISPLAY ION DENSITY VS MASS	I/NO		


2330

Functional Description

This flowchart shows the relationship of the Ion Current vs. Mass computation to the proximate displays involved.




NOTE: ANGLE SPECTROMETER TO \bar{V} GIVEN BY EQN. 218



2335 Functional Description

This flowchart shows the computation of Ion Current versus Mass. Ion Currents depend on quantities of density and temperature which are calculated from previously defined subroutines.


ORIGINAL PAGE IS
OF POOR QUALITY



2350


Flowchart Description

This flowchart shows the relationship of the Ion Density vs. Mass computation to the proximate Displays involved.




ORIGINAL PAGE IS
OF POOR QUALITY

NOTE: ANGLE SPECTROMETER TO \bar{V} GIVEN BY EQN. 218




2357 Functional Description

This flowchart shows the computation of Ion Densities of three species of ions. These densities are based on total electron density and temperature computations done by previously defined subroutines.



Functional Description


This flowchart shows the setup of the neutral mass spectrometer and the computation of the output of this instrument 2430 and 2450.




2400 NEUTRAL MASS SPECTROMETER SETUP DISPLAY		ERROR MSGs	
0: PROCEDURE UP TO		UP/L/D	8: DISPLAY NEUTRAL DENSITY VS MASS L/NO
1: NEUTRAL MASS SPECTROMETER		ON/OFF	9: RECORD INSTRUMENT SETTINGS AND DATA GO/STOP
2: SPARE		READY	
3: SET UPPER MASS LIMIT		XX AMU	
4: SET LOWER MASS LIMIT		XX AMU	
5: SET RESOLUTION		XX AMU	
6: SPARE			
7: DISPLAY NEUTRAL CURRENT VS MASS		L/NO	

Functional Description

This flowchart shows the relationship of the neutral mass spectrometer current vs. mass computation to the proximate displays involved.




NOTE: ANGLE SPECTROMETER TO \bar{V} GIVEN BY EQN. 218




Functional Description

This flowchart shows the computation of spectrometer current, which depends on subroutine 195 outputs of neutral particle density computations.




Functional Description

This flowchart shows the relationship of the Neutral Density vs. Mass Computation to the proximate displays involved.




NOTE: ANGLE SPECTROMETER TO \bar{V} IS GIVEN BY EQN. 218




Functional Description

This flowchart shows the computation of the logarithm of the Densities of the neutral particles, based on the outputs of the subroutine density 195 calculations



Functional Description


This functional description shows both the setup and the processing (2530, 2550) of the Planar Electron Trap data. The linear sweep display 2510 is a check on the instrument's operation.



2500 PLANAR ELECTRON TRAP SETUP DISPLAY		ERROR MSGS	
0: PROCEDURE UP TO		UP/L/O	10: DISPLAY DENSITY VS ENERGY I/NO
1: PLANAR ELECTRON TRAP		ON/OFF	11: RECORD SETTINGS AND DATA 60/STOP
2: SPARE		READY	
3: SET TRAP IN ELECTRON MODE		YES/NO	
4: SET HIGH ENERGY LIMIT		XXXX.eV	
5: SET LOW ENERGY LIMIT		XXXX.eV	
6: SET SWEEP MODE		LIN/SPECIAL	
7: DISPLAY LINEAR SWEEP		60/STOP	
8: SPARE			
9: DISPLAY CURRENT VS VOLTAGE		I/NO	

Functional Description

This flowchart shows the relationship of the Electron Trap Linear Sweep processing to the proximate displays involved.




2515 LINEAR SWEEP DISPLAY
PLANAR ELECTRON TRAP (DEFAULT)

ERROR MSG:

0: PROCEDURE UP/1


UP TO PLANAR ELECTRON TRAP
SETUP DISPLAY (DEFAULT)


1: SPARE



Functional Description


This flowchart shows the relationship of the planar electron trap current vs. voltage computation to the proximate displays involved.






Functional Description


This flowchart shows the computation of Electron current based on the temperatures computed by subroutine 190 and the densities computed by subroutine 199.



Functional Description


This flowchart shows the relationship between the Density vs. Energy computation and the proximate displays involved.






Functional Description

This flowchart shows the computation of electron density, as a function of energy based on the temperature computed from subroutine 190 and the total density of electrons computed from subroutine 199.



Functional Description


This flowchart shows the setup of the Planar Segmented Probe and the Processing of Probe current which is its data output.




2600 PLANAR SEGMENTED PROBE SETUP DISPLAY		ERROR MSG
0: PROCEDURE UP TO	UP/I/D	
1: PLANAR SEGMENTED PROBE	ON/OFF	
	READY	
2: SPARE		
3: PROBE INTO ELECTRON REJECTION MODE	YES/NO	
4: SPARE		
5: SPARE		
6: SPARE		
7: PROBE CURRENT VS TIME	I/NO	
8: RECORD INSTRUMENT SETTINGS AND DATA	GO/STOP	

Functional Description

This flowchart shows the relationship of the Probe Current vs. Time computation to the proximate displays involved.




NOTE: ROLLOVER OF THIS DISPLAY IS REQUIRED FOR THE TIME AXIS. ANGLE PROBE IS GIVEN BY EON, 218.



Functional Description

This flowchart shows the sequence of computations that model the segmented probe current output, based on subroutines 190 and 199. The probe will not make measurements beyond $\gamma = \arctan 2$ and its use at this angle will generate an error message.


ORIGINAL PAGE IS
OF POOR QUALITY



Functional Description

This flowchart shows the processing of recording. All instrument data are recorded for the same time interval for a single recording run. Between runs, the experimenter may choose, via his keyboard, which instrument's settings and data he wishes to record and a new time interval. Recording can proceed whether or not the XXX recording display is ON. Instrument settings are re-recorded only if they are changed, as is orbit mechanics initialization. Time is, of course, recorded along with all other data. The specific experiment involved will determine which instruments are presented on the XXX Record Settings and Data.

ORIGINAL PAGE IS
OF POOR QUALITY



2710 RECORD INSTRUMENT SETTINGS AND DATA DISPLAY		ERROR MSG:	
0: PROCEDURES	UP/1/D		
UP TO		11: RECORD CYCL FL PRBE	GO/STOP READY
1: RECORD FOR	XX MINS	12: RECORD FLUXGATE MAGNETOMETER	GO/STOP READY
2: RECORD FOR	XX SECONDS	13: RECORD RUBIDIUM MAGNETOMETER	GO/STOP READY
3: SPARE		14: RECORD SPHERICAL ION PROBE	GO/STOP READY
4: SPARE		15: RECORD ION MASS SPECTROMETER	GO/STOP READY
5: SPARE		16: RECORD NEUTRAL MASS SPECTROMETER	GO/STOP READY
6: RECORD SETTINGS AND DATA FOR ALL INSTRUMENTS ACTIVE IN THIS EXPERIMENT	GO/STOP READY	17: RECORD ELECTRON TRAP	GO/STOP READY
7: RECORD INITIALIZATION OF ASTRONOMY/ORBIT MECHANICS (ONE-TIME)	GO/STOP READY	18: PLANAR SEGMENTED PROBE	GO/STOP READY
8: RECORD CURRENT VALUES OF ASTRONOMY/ORBIT MECHANICS	GO/STOP READY	RECORD TIME-TO-GO	MINS SECS
9: RECORD BOOM A POSITION	GO/STOP READY	TAPE TIME-TO-GO	MINS SECS
10: RECORD PLATFORM POSITION	GO/STOP READY		

NOTE: IF INSTRUMENTS/BOOMS/COMPUTATIONS COLLECTING THIS DATA ARE NOT READY, AN ERROR MESSAGE WILL BE SHOWN PLUS AN INDICATION IN THE READY BLOCK CONCERNED.

NOTE: DISPLAYED VALUES ARE UPDATED ONCE PER SECOND.

280 TIME AND GEOMETRIC AND
ANGLE DISPLAY SUMMARY

ERROR MSG:

0: PROCEDURE
UP TO

UP/L/D

ANGLE PLATFORM X_p TO ORBITER V DEGREES

1: SPARE

TIME

MET HRS: MINS: SECS

ORBITER ATTITUDE

Γ DEGREES

GMT HRS: MINS: SECS

λ DEGREES

LOCAL TIME LT HRS: MINS

Δ DEGREES

READY

ORBITER POSITION

BOOM A

θ_A DEGREES

EAST LONGITUDE DEGREES

ϕ_A DEGREES

SOUTH LATITUDE DEGREES

LENGTH L_A DEGREES

ALTITUDE KM

READY

READY

PLATFORM

θ DEGREES

MAGNETIC FIELD

χ DEGREES

$|B_z|$ GAMMA

ψ DEGREES

MAGNETIC DIP ANGLE DEGREES

READY

READY

NOTE: DISPLAYED VALUES ARE UPDATED ONCE PER SECOND.

290 PLASMA DENSITY SUMMARY DISPLAY

ERROR MSG:

0: PROCEDURE
UP TO

UP/I/O

NEUTRALS

總發行所
 東京丸の内區
 有樂町一丁目
 丸の内ビルヂング
 五樓五〇二號

PERM

1: SPARE

02

PER M²

總編輯 鄭國治
 副總編輯 鄭國治
 編輯 鄭國治
 編輯 鄭國治
 編輯 鄭國治

PERM

2008年12月
 第12期
 第12期
 第12期

PER M²

IONS

0#

DER M³

READY

02

REF-M3

NO

REF M3

READY

ELECTRONS

000 13

READY

TEMPERATURE

DEGREES
KELVIN

READY

6.3 IONOSPHERIC MEASUREMENTS WITH THE SUBSATELLITE EXPERIMENT

(The experiment procedure for this experiment is given in Section 3.3.2 of the Final Report.)

The present experiment is quite similar to the Passive Observations of the Ambient Plasma Experiment. As might be expected, the experiment data handling simulation of passive observations, functionally does not change appreciably whether the experiment sensors are mounted on a subsatellite or on the orbiter.

The only differences due to the subsatellite, that are built into the present simulation, are time delays to get the subsatellite ejected and into position, and power on, datalink activation and attitude control delays. Section 3.3.3 of the Final Report contains equations for rotating the subsatellite at a rate ω_{sp} that is different from the orbit rate ω . However, this experiment is designed to operate at $\omega_{sp} = \omega$, and Equation 314 is actually used in the form 314.5.

The transformation matrices $T_{A \rightarrow p}$ and $T_{s \rightarrow A}$ of the previous experiments are present in this subsatellite experiment, but have no effect on the computations since each is set equal to the unitary 3×3 matrix. Use is made of these previously derived matrices as a matter of convenience in not having to write changes to existing flowcharts.

6.3.1 Definition of Variables for Ionospheric Measurements with the Subsatellite Experiment

The following definitions define variables used in the flowcharting that follows. For a more comprehensive understanding of the equations involved see the main body of the Final Report.

E_X' , E_Y' , E_Z'

Components of the electric field vector E_{TOT} in the $X'Y'Z'$ (Southward, Eastward, Upward along geocentric radius vector. Range: Plus or minus 10^4 millivolts per meter. Least count: .01 mV/meter.

6.3.2 Typical Values for Ionospheric Measurements with the Subsatellite Experiment

ω_{ps}	Satellite spin rate = Satellite orbit rate ω .
H	Satellite altitude, 300Km above spherical earth.
i	10 degrees.
LT_0	00:00:00 Hrs:Mins:Secs.
GMT_0	00:00:01 Hrs:Mins:Secs.

Satellite Attitude

Λ	80 Degrees
Γ	270 Degrees
Δ	0 Degrees

Matrix Transformations (Eqn. 218)

$T_{A \rightarrow p}$

Ω	0 Degrees
ψ	0 "
χ	0 "

$T_{S \rightarrow A}$

θ_A	0 "
ϕ_A	0 "


Note: Angle Platform X_1 to orbiter $\bar{V} = 0$ degrees in this experiment. Platform X_1 is assumed identical with the subsatellite s_1 axis. This assumption permits us to use previously defined transformations

6.3.3 FLOWCHARTS AND DISPLAY FORMATS FOR

IONOSPHERIC MEASUREMENTS WITH THE SUBSATELLITE EXPERIMENT

Functional Description


This flowchart shows the breakdown of the Ionospheric Measurements with the subsatellite experiment into its principal functional blocks.



22. IONOSPHERIC MEASUREMENTS WITH THE SUBSATELLITE DISPLAY		ERROR MSG.
0: PROCEDURE	UP/I/D	
UP TO PLASMA PHYSICS CHOICE DISPLAY		
1: SUBSATELLITE EJECTION AND INSTRUMENTS	ON/OFF	1/D
2: SPARE	<input type="checkbox"/> READY	1/D
3: INITIALIZATION OF ASTRONOMY/ORBIT MECHANICS	1/D	GO/STOP
4: CURRENT VALUES OF ASTRONOMY/ORBIT MECHANICS	1/D	
5: FLUXGATE MAGNETOMETER SETUP	1/D	
6: CYLINDRICAL ELECTRON PROBE SETUP	1/D	
7: SEGMENTED PLANAR TRAP SETUP	1/D	
8: ION MASS SPECTROMETER SETUP		1/D
9: ELECTRIC FIELD METER SETUP		1/D
10: RECORD INSTRUMENT SETTING AND DATA		GO/STOP

Functional Description

This flowchart shows the processes involved in setting up the electric field meter. In addition to the ON/OFF and warm up computations, this involves extending the field meter antennas and the computations on the electric field meter data themselves



3610 ELECTRIC FIELD METER SETUP DISPLAY

ERROR MSG:

0: PROCEDURES

UP/L/D

UP TO

1: ELECTRIC FIELD METER

ON/OFF

☐ READY

2: SPARE

3: ELECTRIC FIELD METER DATA

GO/STOP

4: RECORD INSTRUMENT SETUP AND DATA

GO/STOP

5: EXTEND/RETRACT ANTENNA

EXT/RET

ANTENNA ☐ READY

LATITUDE LAT

DEGREES

LOCAL TIME

HRS: MINS

ANGLE PLATFORM X, TO V

DEGREES

ALTITUDE

KN

MAGNETIC DIP ANGLE

DEGREES

SOUTHWARD E COMP.

MILLIVOLTS/V

EASTWARD E COMP.

MILLIVOLTS/V

RADIAL E COMP.


MILLIVOLTS/V

TOTAL E FIELD

MILLIVOLTS/V

Functional Description

The Electric Field is assumed generated by the motion of the Orbiter/Spacelab through the Earth's magnetic field. This flowchart shows the computation of the magnetic field components B_x , B_z along the local X' , Y' , Z' axes. It uses these for the computation of the X' , Y' , Z' axis components measured by the electric field meter, which are assumed to be aligned with the satellite axes.



6.4 ELECTRON ACCELERATOR BEAM MEASUREMENTS EXPERIMENT

(The experiment procedure for this experiment is given in Section 3.4.2 of the Final Report.)

The key display in this experiment is Display No. 23 showing the two elements over which the experimenter has direct control: the accelerator setup, and the setup of the Faraday cup which measures the electron beam plasma interaction. As before, the orbit parameters, initially chosen for the experiment are automatically updated once the experiment simulation has begun. In this experiment, although the accelerator setup and Faraday cup setup are done on a building block basis, the actual firing of the accelerator and the associated Faraday cup data collection is done on a combined instrument basis.

In Display 4125, the experiment having been set up, the experimenter can now perform this experiment, while using just this display. Here he can repeatedly fire the accelerator, manipulate the controls that most frequently need adjustment between firings and observe the results. Should the experimenter wish to adjust one of the less frequently adjusted parameters, e.g., photoelectron suppress voltage, then he must back up to the appropriate setup display.

6.4.1 Definition of Variables for Electron Accelerator Beam Measurements Experiment

The following definitions define variables used in the flowcharting that follows. For a more comprehensive understanding of the equations involved see the main body of the Final Report.

V_a	Diverging lens voltage in volts. Range 0 to 1000 volts. Least count 1 volt.
V_c	Converging lens voltage in volts. Range 0 to 1000 volts. Least count 1 volt.
$BPHI = \phi_0$	Beam azimuth of accelerator electron beam, when leaving the accelerator at beginning of firing, relative to orbiter-fixed XYZ coordinates BPHI is measured positive from orbiter +X to the +Y direction in the XY plane. $0 \leq BPHI < 360^\circ$. Least count 0.1 degrees.

$B\Omega$	Beam deflection of accelerator electron beam, when leaving the accelerator at beginning of firing, relative to orbiter-fixed XYZ coordinates. $B\Omega$ is measured positive from orbiter +Z in the BPHI azimuthal plane. $0 \leq B\Omega < 60^\circ$. Least count 0.1 degrees.
ϕ_1	Beam azimuth of accelerator electron beam when leaving the accelerator relative to local magnetic field coordinates, $X_1 Y_1 Z_1$, with Z_1 axis along B vector, X_1 axis in orbiter XY plane and Y_1 axis to form a right-handed Cartesian coordinate system. ϕ_1 is measured positive from X_1 to Y_1 in the $X_1 Y_1$ plane. $0 \leq \phi_1 < 360^\circ$. Least count 0.1 degrees.
Ω_1	Beam deflection of accelerator electron beam when leaving the accelerator, relative to local magnetic field coordinates $X_1 Y_1 Z_1$ with Z_1 axis along B vector, X_1 axis in orbiter XY plane and Y_1 to form a right-handed Cartesian system. Ω_1 is measured positive from the Z_1 axis in the ϕ_1 plane $0 \leq \Omega_1 < 180^\circ$. Least count 0.1 degrees.
$E(\tau_b)$	The energy remaining in the storage bank after a time τ_b seconds of beam firing, in Joules. Range 0 to 100,000 Joules. Least count 1 Joule.
E_0	The maximum energy in the storage bank, Joules. Range 5,000 to 500,000 Joules. Least count 1 Joule.
$E(t_b)$	The energy stored in the storage bank after t_b seconds of charging the bank. Range 5,000 to 500,000 Joules. Least count 1 Joule.
t_b	A time variable used to calculate $D(t)$, the approximate time-to-go until full charge is reached. Range, 0 to 1000 seconds, Least count 1 second.
W_1	The rate of scan of the accelerator beam in the BPHI radians per second. Range 0 to 200π . Least count .01 rad/sec.

W_2	The frequency of the scan of the accelerator beam in the BOMEGA direction, radians per second. Range 0 to 2000π . Least count .01 seconds.
τ_b	Duration planned for beam firing, seconds. Range 0 to 1000. Least count .01 seconds.
$D(t)$	Approximate time-to-go to reach full charge in the energy storage bank in seconds. Range 0 to 1000 seconds. Least count 1 second.
I_h	Cathode Heater Current, amps. Range 0 to 10 amps. Least count 0.1 amps.
I_b	Accelerator beam current, amps. Range 0 to 100 amps. Least count .1 amps.
V_g	Control grid voltage, volts. Range 0 to -100 volts. Least count 0.1 volts.
I_g	Control grid current, milliamps. Range 0 to ± 100 milliamps. Least count 0.1 milliamps.
I_{cup}	Faraday cup current, amps. Range 0 to 100 milliamps. Least count 0.1 milliamps.
t_A	Time variable used to compute accelerator beam azimuth and deflection, seconds. Range 0 to τ_b . Least count .01 seconds.
P	Accelerator potential in volts.
T_f	Time-to-go until beam is fired, in seconds. Range 0 to 240 seconds. Least count 1 second.
τ_d	Time period required to drain energy storage bank, seconds. Range 0 to 1000 seconds. Least count 0.01 seconds.

6.4.2 Typical Values for Electron Accelerator Beam Measurements Experiment

The following values of parameters are considered typical, and may, for example, be used as default values.

V_d	=	100 Volts
V_c	=	100 Volts
BPHI	=	0 Degrees
BOMEGA	=	10 Degrees
E_0	=	100,000 Joules
$D(t)$	=	Counts down from about 48 seconds to zero, if storage bank initially empty.
W_1	=	2π
W_2	=	20π
I_h	=	4.0 Amps
V_g	=	0.0 Volts in test mode -100 Volts during pre-firing mode -5 Volts during firing
P	=	10,000 Volts


ORBITER ATTITUDE, ALTITUDE, INCLINATION

Γ	=	270 Degrees
Λ	=	90 Degrees
Δ	=	0 Degrees
H	=	400 Kilometers
i	=	0 Degrees, Equatorial Orbit

6.4.3 FLOWCHARTS AND DISPLAY FORMATS FOR
ELECTRON ACCELERATOR BEAM MEASUREMENTS EXPERIMENT

Functional Description


This flowchart shows the breakdown of the experiment into its major functions.



23 ELECTRON ACCELERATOR BEAM MEASUREMENTS EXPERIMENT DISPLAY		ERROR MSG:
0: PROCEDURE UP TO PLASMA PHYSICS EXPERIMENT CHOICE DISPLAY	UP/T/D	
1: ELECTRON ACCELERATOR BEAM INSTRUMENTS	ON/OFF	
	<input type="checkbox"/> READY	
2: SPARE		
3: INITIALIZE ASTRONOMY/ORBIT MECHANICS	T/D	
4: CURRENT VALUES OF ASTRONOMY/ORBIT MECHANICS	T/D	
5: ACCELERATOR SETUP	T/D	
6: FARADAY CUP SETUP	T/D	

Functional Description

This flowchart shows the functions performed in setting up the Faraday cup collector, and the proximate displays involved.




4225 FARADAY CUP SETUP DISPLAY		ERROR MSG:
0: PROCEDURE	UP/1/0	
UP TO		
1: FARADAY CUP	ON/OFF	
	READY	
2: SPARE		
3: SET PHOTO ELECTRON SUPPRESS VOLTAGE	XXXX VOLTS	
4: SET AMPLIFIER GAIN	XX db	
5: SET BIAS CONSTANT	MILLIAMPS	
6: SET SCALE FACTOR		

ORIGINAL PAGE IS
OF POOR QUALITY

Functional Description


This flowchart shows the setup of the infrequently changed parameters and the entry to the Test and measurement functions.




4110 ACCELERATOR SETUP DISPLAY		ERROR MSG:
0: PROCEDURE UP TO	UP/1/D	9: DRAIN STORAGE BANK TO ZERO YES/NO
1: ACCELERATOR	ON/OFF <input type="checkbox"/> READY	10: ACCELERATOR TEST 1/D
2: SPARE		11: BEAM MEASUREMENTS DATA 1/D
3: SET DIVERGING LENS VOLTAGE	XXX VOLTS	
4: SET CONVERGING LENS VOLTAGE	XXX VOLTS	
5: SET BEAM INITIAL AZIMUTH	XXX DEGREES	
6: SET BEAM INITIAL DEFLECTION	XXX DEGREES	
7: SET BEAM AZIMUTH SWEEP RATE	XXX.XX RAD/SEC	
8: SET BEAM DEFLECTION FREQUENCY	XXX.XX RAD/SEC	

Functional Description

This flowchart shows the functions and displays needed to check the Accelerator prior to Beam Firing.






Functional Description

This flowchart shows the computation of

Beam azimuth ϕ_1 ,
Beam Deflection Ω_1 ,
Beam Current I , and
Grid Current I_g


that are needed for
Acceleration Test Purposes.

ORIGINAL PAGE IS
OF POOR QUALITY



Functional Description

This flowchart shows the adjustment of the more frequently varied parameters of the accelerator and the principal functions in obtaining data. The storage bank is always charged fully before firing the beam. The operator always sets beam firing T_f into the future, rather than an instantaneous beam trigger.




4:25 BEAM MEASUREMENTS DATA DISPLAY		ERROR MSG:	
0: PROCEDURE	UP TO ACCELERATOR SETUP DISPLAY	UP/I/O	
1: SPARE			
2: FARADAY CUP CURRENT MILLI-AMPS			
3: BEAM Firing DURATION TO MAX Firing DURATION			
4: SET ACCELERATOR VOLTAGE P			XXXXX VOLTS
5: SET CATHODE HEATER CURRENT			X.X AMPS
6: SET CONTROL GRID VOLTAGE			XX.X VOLTS
7: BEAM Firing DURATION TO MAX Firing DURATION			XXX.XX SECONDS
8: SET TIME TO GO UNTIL FIRING			XXX SECONDS
9: FIRING COUNTDOWN			GO/STOP
10: APPROX. TIME TO REACH FULL CHARGE			SECONDS
11: ACCELERATOR			READY
12: RECORD INSTRUMENT SETTINGS AND DATA			GO/STOP
13: LATITUDE			DEGREES
14: LOCAL TIME			HRS:MIN
15: ALTITUDE			KM
16: MAG. DIP ANGLE			DEGREES
17: CHARGING CURRENT			AMPS
18: CHARGING CURRENT			ON/OFF

BEAM ANGLE TO MAGN. FIELD OF DEGREES

TIME FROM FIRING START (SECONDS) T_b

Functional Description

This flowchart shows the countdown of T_f to zero, when the beam fires. t_b is set to zero to support the computation of recharging the energy storage. (See 4129)




ORIGINAL PAGE IS
OF POOR QUALITY

Functional Description


This flowchart shows the computations of the cup current I_c and of the parameters supporting this computation, during the firing time τ_b , 100 samples of the cup current are obtained. The computation of the loss of energy from the storage bank for this firing is done on a single point only.

ORIGINAL PAGE IS
OF POOR QUALITY




Functional Description

This flowchart shows the computation of the τ_d time required to drain the energy storage bank at a certain current I and voltage level P . If the planned firing time τ_b exceeds τ_d an error message is shown.



Functional Description

This flowchart shows the computation of the time-to-go at which the full charge will be reached. Because of non-linearity of the equations, the time-to-go functions $D(t)$ is an approximate measure of the time required to charge the storage Bank. Charging is continued until E_{tb} is within 500 Joules of full charge. The flow is idealized in that it assumes no leakage from the storage bank. This computation 4129 is reactivated after each firing unless charging current is turned OFF. Charging computations are continued whether or not display 4125 is activated, until storage bank is full or charging current turned off.



ORIGINAL PAGE IS
OF POOR QUALITY

6.5 LIDAR TRACE OF ACOUSTICAL GRAVITY WAVES IN THE SODIUM LAYER

(The procedure for this experiment is given in Section 3.5.2 of the Final Report.)

The key display for this experiment is Display No. 14, which initializes and maintains the orbit, as well as permitting the experimenter to set up the lidar transmitter, receiver and to make his measurements and recordings. In this experiment it is assumed that the lidar is pointing toward the geocenter. Once again the instrument setups are flowcharted on a building block basis but this time the building blocks have been even more finely divided in that the lidar transmitter (915) and receiver (925) setup displays have been placed in separate blocks.

To set up the transmitter there has been added special tests of absorption cell readiness (Display No. 9195), transmitter output spectrum calculation (Display No. 9175), and other checks (photon count, etc.). However the sodium layer measurements themselves are again combination displays where the experimenter can make repeated firings and decide whether or not to record the results, or else change the altitude limits, and altitude resolution (Display No. 945). This experiment gives the experimenter considerable latitude in his choice of output measurement displays, there being four different choices given (Display No's. 9435, 9445, 9455, and 9465).

6.5.1 Definition of Variables for Lidar Trace of Acoustical Gravity Waves in the Sodium Layer

The following definitions define variables used in the flowcharting that follows. For a more comprehensive understanding of the equations involved see the main body of the Final Report.

P_L	Power Level of flashlamp in Watts. Range 0 to 1000 Watts. Least Count 1 Watt.
P_E	Energy in a Single Pulse in Joules. Range 0.1 to 10.0 Joules. Least Count 0.1 Joule.
T_R	Time Interval between start of successive laser firings in seconds. Range 0.1 to 100 seconds. Least Count 0.1 second.
FS	Field Stop Value. Range 0.01 to 100.00 milliradians. Least Count .01 milliradian.

BD	Transmitted Beam Divergence. Range 0.01 to 10.00 milliradians. Least Count 0.01 milliradian.
BT	Range of Wavelength of Spectrometer. Range 300 to 800 nm. Least Count 0.1 nm.
FT	Tine Tune Capability of Fabry-Perot. Range Least Count 0.01 nm.
RES	Resolution achievable by Spectrometer. Range 10,000 to 0.001 nm. Least Count 0.001 nm.
Top	Absorption Cell Operating Temperature. Range 100 to 1000°C. Least Count 1°C.
Z	Altitude of atmosphere observed as measured from earth surface. Range 0 to 500 KM. Least Count 0.01 KM.
ΔZ	Altitude Resolution element being observed. Range 10^2 to 10^5 meters. Least Count 10 meters.
Xo	Value of X at N (number of firings) = 0.
X	Distance measured along orbiter circle of altitude at orbiter altitude between Greenwich Meridian Plane and current orbiter position. Measured Eastward from Greenwich Meridian Plane.
UTH	Greenwich Mean Time in Decimal Hours.
λ_z	Center wavelength of wavelength spectrum transmitted.
RES _{FP}	Receiver Resolution Element. Range 100.000 nm to 0.001 nm Least Count 0.001 nm.
AP	Receiver Aperture Setting. Range 0 to 100 Least Count 1.
$P\lambda$ min, $P\lambda$ max	Minimum and maximum wavelengths of the transmitter pulse.
η	Angle between altitude and distance axes, degrees Range 30° to 80°. Least Count 1°.

O_x, O_y	x, y coordinates of origin on MFDS CRT display screen for $N = 0$.
N	Number of laser firings contributing to an output display.
S	Scale value at which tic mark will be displayed on graphic display axis.

6.5.2 Typical Values of Lidar Trace of Acoustical Gravity Waves in the Sodium Layer

The following values of parameters are considered typical, and may, for example, be used as default values.

ORBITER ATTITUDE, ALTITUDE, INCLINATION

Γ	180 Degrees
Λ	180 Degrees
Δ	0 Degrees
H	180 Kilometers
i	27 Degrees

LASER PARAMETERS

P_L	1000 Watts
P_E	10.0 Joules
T_R	1.00 Hz
BD	1.00 Milliradians
FS	100 Milliradians
BT	589.0 Nanometers

RES	10 Nanometers
RES _{FP}	0.01 Nanometers
FT	50
P λ max	590 Nanometers (Power Meter Upper Limit)
P λ min	580 Nanometers (Power Meter Lower Limit)
λ_1	588.99 Nanometers
% Absorption Cell Transmission	80%
AL	0.00 Degrees Transmitter Azimuth Alignment
EL	0.00 Degrees Transmitter Elevation Alignment
ΔZ	0.1 KM
Z Minimum Value	80 KM
Z Maximum Value	100 KM
λ_{min}	300 Nanometers Lower Limit of Laser Transmission
λ_{max}	800 Nanometers Upper Limit of Laser Transmission
Angle +Z Axis to Nadir	0 Degrees
Top	800 Degrees Celsius

6.5.3 FLOWCHARTS AND DISPLAY FORMATS FOR


LIDAR TRACE OF ACOUSTICAL GRAVITY WAVES IN THE SODIUM LAYER

Functional
Description

This flowchart shows the processes in changing the scale of the Abcissa Axis.

A similar flowchart could be drawn for the Ordinate Axis of a 2-axis display.

ORIGINAL PAGE IS
OF POOR QUALITY




C.3

ORIGINAL PAGE 13
OF POOR QUALITY

Functional Description


This flowchart shows the break-down of the LIDAR trace of acoustical gravity waves in Sodium Layer Experiment into its major functional components.



245 LIDAR TRACE OF ACQUSTICAL GRAVITY WAVES IN SODIUM LAYER		ERROR MSG:	
0: PROCEDURE UP TO PLASMA PHYSICS EXPERIMENT	UP/1/D	10: SPARE	11: RECORD INSTRUMENT SETTINGS & DATA GO/STOP
1: LIDAR EXPERIMENT INSTRUMENTS	ON/OFF		
2: SPARE	<input type="checkbox"/>	READY	
3: INITIALIZATION OF ASTRONOMY/ORBIT MECHANICS	1/D		
4: CURRENT VALUES OF ASTRONOMY/ORBIT MECHANICS	1/D		
5: LIDAR TRANSMITTER SETUP	1/D		
6: LIDAR RECEIVER SETUP	1/D		
7: SPARE			
8: SPARE			
9: LIDAR MEASUREMENTS & CONTROL	1/D		


Functional Description

This simple computation is carried out to assure the experimenter that the laser beam which is aligned to the Orbiter +Z axis will be pointing always to the Earth's center.



Functional Description


This flowchart shows the breakdown of the transmitter set up into its component parts.



915 LIDAR TRANSMITTER SETUP DISPLAY		ERROR MSG:	
0: PROCEDURE	UP/1/D	10: POWER MEASUREMENT AND CONTROL	1/D
1: SPARE		11: SPARE	
2: LIDAR TRANSMITTER INSTRUMENTS	ON/OFF	12: SPARE	
	<input type="checkbox"/>	13: SET BEAM DIVERGENCE	XX.XX MILLIRADIANS
		14: SET AZIMUTH ALIGN (AL)	X.XX DEGREES
3: SPARE		15: SET ELEVATION ALIGN (EL)	X.XX DEGREES
4: SPARE		16: AUTOMATIC ALIGNMENT	GO/STOP
5: SPARE		17: MANUAL ALIGNMENT	1/NO/D
6: SPARE			
7: SPARE			
8: RHODAMINE G G	YES/NO		
CONTROL AND ALIGNMENT			
9: TUNING MEASUREMENT AND CONTROL	1/D		


Functional Description

This flowchart shows on/off settings required to be met to tune the Laser Transmitters. The output spectrum can be checked via 9170.



Functional Description

This flowchart shows the more detailed settings required to activate the Laser output calculations.



9175 TRANSMITTER OUTPUT SPECTRUM
DISPLAY

LEPROUS WSG

10: PROCEDURE

UP TO TRANSMITTER TUNING SETUP DISPLAY

UP/I/O

6: BROAD-BAND RESOLUTION

XX, X, M

1. SPARE

2.2 LOWER BOUND LENGTH LIMIT

XXXX, X MM

8: FABRY-PEROT WAVELENGTH

XXXXX.XX nm

3: UPPER WAVELENGTH LIMIT

XXX. A AM

9: FABRY-PÉROT RESOLUTION

X. XX. 04

4: TIC MARK INTERVAL


XXX, X nm

NO: COMPUTE OUTPUT SPECTRUM

GO/STOP


5. BROAD-BAND WAVELENGTH

XXXX.X MM



This flowchart shows the detailed computations of the output spectrum produced by the transmitter, whether the Fabry-Pero t is in the beam or out of the beam. The computation is started at λ_0 and proceeds until the computation either passes the λ_{\max} , λ_{\min} limits or the $.01 I(\lambda_0)$ limit, to avoid computing an excessive number of points.


ORIGINAL PAGE IS
OF POOR QUALITY



Functional Description

This flowchart shows the parameter settings required to make the receiver ready to take measurements.


ORIGINAL PAGE IS
OF POOR QUALITY



925 LIDAR RECEIVER SETUP DISPLAY		ERROR MSG.
0: PROCEDURE UP TO	UP/3/D	9: DUST COVER ON/OFF
1: LIDAR RECEIVER	ON/OFF	10: SELECT DETECTOR HI-VOLTAGE XXXX VOLTS
ARMED UP	READY	RECEIVER READY FOR MEASUREMENTS
2: SPARE		
3: SET APERTURE	XXX DIAMETER	
4: SET FIELD STOP	XXX X MILLIRADIANS	
5: SODIUM D-LINE FILTER	IN/OUT OF THE BEAM	
6: FABRY-PEROT MOTOR	ON/OFF	
7: SET FABRY-PEROT RECEIVER BAND- PASS (RES-FP)	X.XXX NM	
8: SET RECEIVER CENTRAL WAVELENGTH	XXX.XX NM	

Functional
Description


This flowchart shows
all the operations
that are checked so
that the simulation
will recognize
receiver readiness.



Functional Description

This flowchart shows the functions required to set up the Lidar Transmitter. It also contains the functions required to test fire the laser at a low power level before turning on full power.


ORIGINAL PAGE IS
OF POOR QUALITY



9195 POWER MEASUREMENT AND CONTROL DISPLAY		ERROR MSG:	
0: PROCEDURE UP TO TRANSMITTER SETUP DISPLAY		11: ABSORPTION CELL	11: OUT OF THE BEAM
		12: CELL ON/OFF & CONTROL	ON/OFF
		13: SET MAX TEMPERATURE	XXX CELSIUS
1: LASER POWER SUPPLY		CELL	READY
		CELL TEMPERATURE	DEGREES CELSIUS
2: SPARE		TRANSMISSION	PERCENT
3: LASER POWER LEVEL		14: PHOTOTUBE #2	ON/OFF
4: LASER PULSE ENERGY			
5: LASER PULSE FREQUENCY			
			LASER COUNTDOWN
		15: LASER TIME-TO-GO UNTIL FIRE	XX SECONDS
6: CALCULATE ENERGY IN LASER PULSE		16: LASER COUNTDOWN	GO/STOP
PULSE ENERGY		TIME-TO-GO UNTIL FIRE	SECONDS
7: POWER METER			
			PHOTON COUNT
8: SPARE		PHOTON COUNT	PHOTONS
9: SET LOWER WAVELENGTH P> MAX		17: PHOTOTUBE #3	ON/OFF
10: SET UPPER WAVELENGTH P> MIN			
		18: DUST COVER	ON/OFF
ABSORPTION CELL			

Functional Description


See Flowchart 919



Functional Description


This flowchart checks the limitations on individual laser pulse energy against total (flask lamp) wattage.

ORIGINAL PAGE IS
OF POOR QUALITY




Functional Description

This flowchart shows the simulation of the heating of the absorption cell as a function of time. When the absorption cell has reached the operating temperature, TOP, this is maintained until the cell is turned off.




Functional Description

This flowchart shows the items that are checked prior to firing the transmitter and the countdown gives the operator a chance to "get set" to observe the data.



Functional Description


This flowchart gathers in one place all the operations that should be performed to assure transmitter readiness.



Functional
Description


This flowchart shows
the computation of
the percent of trans-
mitter energy that is
transmitted through
the absorption cell.

ORIGINAL PAGE IS
OF POOR QUALITY



Functional Description


This flowchart shows the calculation of the number of photons N_{ph} output in a single laser pulse, based on the pulse energy E_l keyed in and the center wavelength λ_l selected.



ORIGINAL PAGE IS
OF POOR QUALITY

Functional Description


This flowchart shows five options that the experimenter has for obtaining the various displays that present the data. The altitude quantities (that are fairly frequently adjusted) are adjustable via this flowchart also.



945 LIDAR MEASUREMENTS CONTROL DISPLAY		ERROR MSG.	
0:	PROCEDURE	UP/I/D	LATITUDE DEGREES
1:	SPARE		LONGITUDE DEGREES
2:	SET UPPER ALTITUDE LIMIT	XXX.X Km	LOCAL TIME HRS-MINS
3:	SET LOWER ALTITUDE LIMIT	XXX.X Km	ORBITER ALTITUDE Km
4:	SET ALTITUDE RESOLUTION ΔZ	X.XX Km	ANGLE ORBITER +Z TO NADIR DEGREES
5:	SPARE		
6:	SPARE		
7:	RAW COUNTS VS. ALTITUDE	I/D	
8:	NO DENSITY VS. ALTITUDE	I/D	
9:	DENSITY MINUS AVERAGE DENSITY	I/D	
10:	DENSITY MINUS AVERAGE DENSITY VS. (POSITION) DISTANCE	I/D	
11:	DENSITY MINUS AVERAGE DENSITY VS. (POSITION) DISTANCE & ALTITUDE	I/D	


Functional
Description


This flowchart shows
the Night versus day
computation that
supports the
computation of which
are forbidden (day)
times to gather the
data of this
experiment.



Functional Description

This flowchart shows the functions required for computing photon counts received in making simulated LIDAR measurement. Transmitter and receiver readiness is checked and a recording option is provided.






ORIGINAL PAGE IS
OF POOR QUALITY

Functional Description


This flowchart shows the detailed computations that are involved in computing the Photon count. This count depends on numerous instrument settings made previously. The Count is presented due to a single Laser firing and presents all resolution elements ΔZ from the minimum up to the maximum altitude as data points.



Functional Description

This flowchart is identical to 9420 except that the computation is carried one step further to compute Na density directly instead of stopping at Photon Counts.

ORIGINAL PAGE IS
OF POOR QUALITY




[illegible]

Functional Description


The flowchart shows the detailed computations that are involved in computing Na Density. The output profile of this computations resembles that of 9427, however, only geometric factors enter into the computation. The instrument settings are not involved as they are in 9427.


ORIGINAL PAGE IS
OF POOR QUALITY



Functional Description


This flowchart shows the functions required for computing the Na density minus average density required. This flowchart is identical to 9430 with the exception that the average density $\rho(Na)$ is subtracted from each value of $\rho(Na)$ computed.






Functional Description


For each altitude increment ΔZ , this flowchart computes $\rho(na) - \bar{\rho}(Na)$.



Functional Description

This flowchart shows the overall functions for computing Na density minus average Na density for a constant altitude Z_1 . Abcissa scale and tic marks adjustment are provided to permit adjustment of horizontal distance scale for various orbital situations.






Functional
Description

This flowchart
computes $\rho(Na) - \rho(Na)$.

In order to start
the abscissa x_0 of
9455 at zero
kilometers distance,
all subsequent
iterations are
displayed relative
to x_0 .

ORIGINAL PAGE IS
OF POOR QUALITY




Functional Description


This flowchart shows the functions required for computing a 3-dimensional display. These include Na density vs avg. density, distance and altitude. On the display 9465, each firing generates a separate density altitude curve.

The experimenter can adjust distance scale, firing rate and 3rd axis angle to obtain maximum information from the presentation of the data.

ORIGINAL PAGE IS
OF POOR QUALITY

0:UP






Functional Description

This flowchart shows the computation of the "3-dimensional" display parameters of 9465. The logic flow is a combination of the flows used for Density & Altitude and Density vs. Distance equations. For each laser firing N the origin of coordinates moves by an amount depending on the horizontal distance X_N travelled by the orbiter.

ORIGINAL PAGE IS
OF POOR QUALITY



6.6 ADDITIONAL FLOWCHARTS: CONVERSION OF UNITS AND CALIBRATION DATA

In the current conception of the CVT simulation, the simulation of the physical environment takes place directly in scientific units. These same scientific units are (in most cases) used for display and recording.


The attached flow charts supplement the above concept should the CVT simulation be extended to include hardware elements and special display and data recording format requirements.

Flowchart 207 unpacks data words, converts or calibrates data to scientific units and limit checks these. Flowcharts 208 and 209 convert the scientific data for display and for recording output formats, respectively, and limit checks these again to be sure that they will fit the output equipment.

207 FUNCTIONAL DESCRIPTION

This flowchart shows the steps taken in converting data outputs from simulated instrument measurements to scientific units, and the limit checking of this data after conversion.


CONSULT TABLE OF TOLERANCE LIMITS APPLICABLE TO THE PARTICULAR INSTRUMENT OUTPUT CONVERTED



ORIGINAL PAGE IS
OF POOR QUALITY

208 Functional Description

This flowchart shows the conversion of instrument data from scientific units to units specified by the display formats, and the limit checking of the data to be displayed to ensure display compatibility.



ORIGINAL PAGE IS
OF POOR QUALITY

209 Functional Description

This flowchart shows the conversion of instrument data in scientific units to a format suitable for data recording. All data are limit checked to ensure that each data value is flagged as being in/out of tolerance.

